Original		Sustituto	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
MEDIA PLAYER	Media Player	6	6
TV AUDIO	TV/Audio	7	7
AUX2	AUX2	8	8
TUNER	Tuner	9	9
USB	USB	-/-- GUIDE	Guide
CD	CD	0	0
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
·:I:·	·:I:·	HOME SMART	Smart
INTERNET RADIO	Internet Radio	APP MEDIA	Media
CH/PAGE	CH/Page+	+ CH	Ch +

Original		Sustituto	
CH/PAGE	CH/Page-	CH –	Ch -
ECO	Eco	ECO 3D	3D
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
TUNE–	I<<<Tune-	I<<<	I<<<
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause

Original		Sustituto	
TUNE +	>>I / Tune+	>>I	>>I
1	Smart Select 1	E-MANUAL D.MENU	D. Menu
3	Smart Select 2	REPEAT TEXT	Text
2	Smart Select 3	ZOOM	Eject
4	Smart Select 4	TIMER AV	AV
MOVIE	Green/Movie	B	Green
MUSIC	Red/Music	A	Red
GAME	Blue/Game	D	Blue
PURE	Yellow/Pure	C	Yellow

Original	Sustituto

Original		Sustituto	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
MEDIA PLAYER	Media Player	6	6
TV AUDIO	TV Audio	7	7
AUX2	AUX2	8	8
TUNER	Tuner	9	9
USB	USB	-/-- GUIDE	Guide
CD	CD	0	0
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
	·:I:·	HOME SMART	Smart
INTERNET RADIO	Internet Radio	APP MEDIA	Media
CH/PAGE	CH/Page+	+ CH	Ch +

Original		Sustituto	
CH/PAGE	CH/Page-	CH −	Ch -
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
TUNE−	I<<Tune-		I<<
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
TUNE+	>>I/Tune+		>>I
1	Smart Select 1	E-MANUAL D.MENU	D. Menu
2	Smart Select 2	REPEAT TEXT	Text
3	Smart Select 3	ZOOM	Eject

Original	Sustituto	Original	Sustituto
4 Smart Select 4	TIMER AV		