Original		Sustituto	
	Power		Power
	Mute	MUTE	Mute
	Rec	REC MODE	Rec
GOTO	Goto	HOME SMART	Smart
ASPECT	Aspect	ECO 3D	3D
V.FORMAT	V. Format	PICTURE FORMAT	Format
	<<		<<
	>>		>>
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
TV/RADIO	Tv/ Radio	SEARCH TV/R	TV/ R
AUDIO	Audio	SOUND DUAL	Dual
DEV	Dev	SETTINGS OPT	Options
RECALL	Recall	RETURN BACK	Back
TTX	Red/ TTX	A	Red
SUB.T	Green/ SUB. T	B	Green

Original		Sustituto	
ZOOM	Yellow/ Zoom	C	Yellow
OPTION	Blue/ Option	D	Blue
INFO	Info	DISPLAY INFO	Info
FAV	FAV	FAV PRE-CH	Pre Ch
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
CH+	Up/ CH+		Up
CH-	Down/ CH-		Down
VOL+	Right / Vol +		Right
VOL-	Left / Vol -		Left
OK	OK	OK	Ok
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
SAT	SAT	APP MEDIA	Media
EPG	EPG	GUIDE	Guide
PAGE+	Page+	CH +	Ch +
PAGE-	Page-	CH -	Ch -

Original		Sustituto		Original	Sustituto
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
FIND	Find	TIMER AV	AV		
MP	MP	DISC NAV LIST	List		