Mandis shop

# Panasonic VEQ1195

| Original | Sustituto | Original | Sustituto |
|---|---|---|---|
| Operation | Power | | |
| Audio Out | Mute / Dimmer | | |
| Rec | Rec / Rec Mode | | |
| Pause / Still | Pause / Step / Freeze | | |
| Still ADV | Right | | |
| Stop | Stop / Hold | | |
| Rew | << / Tune- | | |
| FF | >> / Tune+ | | |
| Play | Play / Slow | | |
| Slow | OK | | |
| Slow | SHIFT + SLOW | | |
| Slow- | Down | | |
| Slow+ | Up | | |
| | | | |
| | | | |
| | | | |
| | | | |

https://mandis.es/es/Panasonic/1033-952-mando-sustituto-para-Panasonic-VEQ1195.htm