Mandis shop

Panasonic N2QAYC000081

Original		Sustituto	
	Power		Power
iPod	Eject iPod	SHIFT + SURROUND	Shift + Eject / Surround
CD	Eject CD	SURROUND	Eject / Surround
iPod/ USB	iPod USB	LIST SMART	Smart / List
CD/ RADIO	CD/ Radio	PROGRAM TV/ RADIO	TV/ Radio /
	Bluetooth	BLUETOOTH 9	9
	I <<<| <<	TUNE-	<< / Tune-
►/II	Play	SLOW	Play / Slow
►/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
►►/►►I	>>| >>I	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
VOL–	Vol -	VOL –	Vol -
VOL+	Vol +	+ VOL	Vol +
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
iPod MENU DISPLAY	Display/ iPod	MEDIA DISPLAY	Display / Media
SOUND	Sound	TITLE SOUND	Sound / Title

Original		Sustituto	
PLAY MENU	Play Menu	APP REPEAT	Green / APP / Repeat
▼	Album Up	▲	Up
OK	OK	OK	OK
▲	Album Down	▼	Down

https://mandis.es/es/Panasonic/1665-634-mando-sustituto-para-Panasonic-N2QAYC000081.htm