Mandis shop

Philips RC-5721

Original		Sustituto	
	Power		Power
	Open/Close	ZOOM	Eject
	Home	HOME SMART	Smart
DISC MENU	Menu/Disc	TOP MENU MENU	Menu
OPTIONS	Options	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
STOP	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	I<		I<<
	>I		>>I
	>>		>>
	<<		<<
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Sustituto	
OK	OK	OK	Ok
SUBTITLE	Subtitle	AD SUBT	Subt
GOTO	Goto	- / -- GUIDE	Guide
AUDIO	Audio	SOUND DUAL	Dual
	[<>]	PICTURE FORMAT	Format
VOLUME	Volume	APP MEDIA	Media
REPEAT / REPEAT A-B	Repeat/Repeat	REPEAT TEXT	Text

https://mandisremotes.com/es/Philips/1057985-23619-mando-de-sustitucion-para-Philips-RC-5721-996510056836.html