Original		Sustituto	
STANDBY	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PROGRAM	Program	PROG SLEEP	Sleep
RETURN TITLE	Title/Return	RETURN BACK	Back
SYSTEM MENU	Menu/System	TOP MENU MENU	Menu
DISC MENU	Menu/Disc	E-MANUAL D.MENU	D. Menu
OK	OK	OK	Ok
	Up		Up

Original		Sustituto	
	Down		Down
	Right		Right
	Left		Left
	I <<		I <<
	>>I		>>I
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
MUTE	Mute	MUTE	Mute
TV VOL +	Tv Vol +	CH +	Ch +
TV VOL -	Tv Vol -	CH -	Ch -
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	SETTINGS OPT	Options
ZOOM	Zoom	ZOOM	Eject
AUDIO	Audio	SOUND DUAL	Dual

Original	Sustituto	Original	Sustituto
REPEAT Repeat	REPEAT TEXT Text		
REPEAT A-B A-B Repeat	A Red		
BASS Bass	HOME SMART Smart		
TREBLE Treble	APP MEDIA Media		
SURR. Surr.	TIMER AV AV		
SOUND Sound	SHIFT + SOUND DUAL Shift + Dual		
NIGHT Night	ECO 3D 3D		
CD UP SAMP. CD UP Samp.	C Yellow		
DIM DIM	FAV PRE-CH Pre Ch		
DISPLAY Display	DISPLAY INFO Info		

Original		Sustituto	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PROGRAM	Program	PROG SLEEP	Sleep
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Sustituto	
	I <<		I <<
	>>I		>>I
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
TV VOL +	Tv Vol +	CH +	Ch +
TV VOL -	Tv Vol -	CH -	Ch -
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
BASS	Bass	HOME SMART	Smart
TREBLE	Treble	APP MEDIA	Media
SURR.	Surr.	TIMER AV	AV
SOUND	Sound	SOUND DUAL	Dual
NIGHT	Night	ECO 3D	3D
DIM	DIM	FAV PRE-CH	Pre Ch
MUTE	Mute	MUTE	Mute

Original		Sustituto	
STANDBY	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PROGRAM	Program	PROG SLEEP	Sleep
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Sustituto	
I<<	I <<	I<<	I <<
>>I	>>I	>>I	>>I
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
TV VOL +	Tv Vol +	CH +	Ch +
TV VOL -	Tv Vol -	CH -	Ch -
MUTE	Mute	MUTE	Mute
BASS	Bass	HOME SMART	Smart
TREBLE	Treble	APP MEDIA	Media
SURR.	Surr.	TIMER AV	AV
SOUND	Sound	SOUND DUAL	Dual
NIGHT	Night	ECO 3D	3D
DIM	DIM	FAV PRE-CH	Pre Ch
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop