Original		Sustituto	
	Power		Power
DISC	Red/Disc	NETFLIX SEARCH	Red / Netflix / Search
DOCK for iPod	Green/Dock for	APP REPEAT	Green / APP / Repeat
HELP	Yellow/Help	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SOURCE	Blue/♪ Source	Prime Video RANDOM	Blue / Prime Video / Random
	Home	SHIFT + HOME MENU	Shift + Menu /
DISC MENU POP-UP MENU	Pop-Up Menu/Disc Menu	HOME MENU	Menu / Home
	Up		Up
SOUND SETTINGS	Sound Settings	LANG I/II AUDIO	Audio / Lang I/II
	Left		Left
OK	OK	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
OPTIONS	Options	OPT-TOOLS SETUP	Setup / OPT /
	Vol -	VOL –	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer

Original		Sustituto	
	Vol +	+ VOL	Vol +
	Stop	HOLD	Stop / Hold
	Eject	SURROUND	Eject / Surround
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	I <	PRESET-	I << / Preset-
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	>I	PRESET+	>>I / Preset+
1.@	1	TV 1	1
2 ABC	2	DVD 2	2
DEF 3	3	CD-STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
MNO 6	6	TUNER 6	6
7 PQRS	7	AUX-HDD 7	7
8 TUV	8	USB 8	8

Original		Sustituto	
WXYZ 9	9	BLUETOOTH 9	9
TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
0	0	HDMI - SAT 0	0
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ

Original	Sustituto