Original		Sustituto	
STANDBY/ON	Standby / On		Power
ECO	ECO	ECO 3D	3D
D AUX	D AUX	1	1
A AUX	A AUX	2	2
iPod USB	iPod USB	3	3
NETWORK	Network	4	4
ADAPTER	Adapter	5	5
TUNER	Tuner	6	6
BD	BD	7	7
DVD	DVD	8	8
CD	CD	9	9
STB	STB	GUIDE	Guide
GAME	Game	0	0
TV	TV	SEARCH TV/R	TV/R
PORTABLE	Portable	FAV PRE-CH	Pre Ch
S.RTRV	S RTRV	SOUND DUAL	Dual
AUTO/ DIRECT	Auto / Direct	A	Red

Original		Sustituto	
ALC/ STANDARD	ALC / Standard	B	Green
ADV SURR	Adv Surr	C	Yellow
SLEEP	Sleep	PROG SLEEP	Sleep
SLEEP	Repeat	SHIFT + REPEAT TEXT	Shift + Text
SP-AB	Speakers	D	Blue
SP-AB	Shuffle	SHIFT + SEARCH TV/R	Shift + TV/R
AUDIO DIMMER	Dimmer	REPEAT TEXT	Text
DISP STATUS	Status	DISPLAY INFO	Info
DISP STATUS	Disp	SHIFT + DISPLAY INFO	Shift + Info
MENU TOOLS	Tools	SETTINGS OPT	Options
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
iPod CTRL HOME MENU	Home Menu	TOP MENU MENU	Menu
iPod CTRL HOME MENU	iPod CTRL	E-MANUAL D.MENU	D. Menu

Original		Sustituto		Original		Sustituto	
RETURN	Return	RETURN BACK	Back				
VOL +	Vol +	+ VOL	Vol +				
VOL -	Vol -	VOL −	Vol -				
MUTE	Mute	MUTE	Mute				
⏸	Pause	SHIFT + ⏸	Shift + Pause				
PTY ■	PTY	HOME SMART	Smart				
PTY ■	Stop	SHIFT + ■	Shift + Stop				
BAND ▶	Band	APP MEDIA	Media				
BAND ▶	Play	SHIFT + PLAY MODE ▶	Shift + Play				
PRE ⏮	Preset -	⏮	I <<				
PRE ⏮	I <<	SHIFT + ⏮	Shift + I <<				
SET + ⏭	Preset +	⏭	>>I				
SET + ⏭	>>I	SHIFT + ⏭	Shift + >>I				
TU ◀◀	Tune-	◀◀	<<				
TU ◀◀	<<	SHIFT + ◀◀	Shift + <<				
▶▶	Tune+	▶▶	>>				
▶▶	>>	SHIFT + ▶▶	Shift + >>				

Original		Sustituto	
STANDBY/ON	Standby / On		Power
ECO	ECO	ECO 3D	3D
D AUX	D AUX	1	1
A AUX	A AUX	2	2
iPod USB	iPod USB	3	3
NETWORK	Network	4	4
ADAPTER	Adapter	5	5
TUNER	Tuner	6	6
BD	BD	7	7
DVD	DVD	8	8
CD	CD	9	9
STB	STB	-/-- GUIDE	Guide
GAME	Game	0	0
TV	TV	SEARCH TV/R	TV/R
PORTABLE	Portable	FAV PRE-CH	Pre Ch
S.RTRV	S RTRV	SOUND DUAL	Dual
AUTO/ DIRECT	Auto / Direct	A	Red

Original		Sustituto	
ALC/ STANDARD	ALC / Standard	B	Green
ADV SURR	Adv Surr	C	Yellow
SLEEP	Sleep	PROG SLEEP	Sleep
SLEEP	Repeat	SHIFT + REPEAT TEXT	Shift + Text
SP-AB	Speakers	D	Blue
SP-AB	Shuffle	SHIFT + SEARCH TV/R	Shift + TV/R
AUDIO DIMMER	Dimmer	REPEAT TEXT	Text
DISP STATUS	Status	DISPLAY INFO	Info
DISP STATUS	Disp	SHIFT + DISPLAY INFO	Shift + Info
MENU TOOLS	Tools	SETTINGS OPT	Options
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
iPod CTRL HOME MENU	Home Menu	TOP MENU MENU	Menu
iPod CTRL HOME MENU	iPod CTRL	E-MANUAL D.MENU	D. Menu

Original		Sustituto	
RETURN	Return	RETURN BACK	Back
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
PAUSE	Pause	SHIFT + PAUSE	Shift + Pause
PTY	PTY	HOME SMART	Smart
STOP	Stop	SHIFT + STOP	Shift + Stop
BAND	Band	APP MEDIA	Media
PLAY	Play	SHIFT + PLAY MODE	Shift + Play
PRESET -	Preset -	I<<	I<<
I<<	I<<	SHIFT + I<<	Shift + I<<
PRESET +	Preset +	>>I	>>I
>>I	>>I	SHIFT + >>I	Shift + >>I
TUNE -	Tune-	<<	<<
<<	<<	SHIFT + <<	Shift + <<
TUNE +	Tune+	>>	>>
>>	>>	SHIFT + >>	Shift + >>

Original	Sustituto