Original		Sustituto	
	Power		Power
SOURCE	Source	TIMER AV	AV
HDMI	HDMI	HOME SMART	Smart
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -

Original		Sustituto	
MUTE	Mute	MUTE	Mute
CH LIST	CH. List	DISC NAV LIST	List
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
	Smart Hub	APP MEDIA	Media
GUIDE	Guide	GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
A	Red	A	Red

Original		Sustituto		Original	Sustituto
B	Green	B	Green		
C	Yellow	C	Yellow		
D	Blue	D	Blue		
Family Story	Family Story	E-MANUAL D.MENU	D. Menu		
SEARCH	Search	SEARCH TV/R	TV/R		
DUAL I-II	Dual I-II	SOUND DUAL	Dual		
SUPPORT	Support	ECO 3D	3D		
P.SIZE	P. Size	PICTURE FORMAT	Format		
AD/SUBT.	AD/Subt	AD SUBT	Subt		
◀◀	<<	◀◀	<<		
I◀◀	I<<	I◀◀	I<<		
❚❚	Pause	❚❚	Pause		
▶▶	>>	▶▶	>>		
▶▶I	>>I	▶▶I	>>I		
●	Rec	REC MODE ●	Rec		
▶	Play	PLAY MODE ▶	Play		
■	Stop	■	Stop		