Original		Sustituto	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
+	Vol +	+ VOL	Vol +
—	Vol -	VOL —	Vol -
MUTE	Mute	MUTE	Mute

Original		Sustituto	
CH LIST	CH List	DISC NAV LIST	List
P	P+	+ CH	Ch +
P	P-	CH —	Ch -
CONTENT	Content	SHIFT + SETTINGS OPT	Shift + Options
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
▲	Up	▲	Up
◀	Left	◀	Left
OK	Enter	OK	Ok
▶	Right	▶	Right
▼	Down	▼	Down
RETURN BACK	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
A	Red	A	Red
B	Green	B	Green

Original		Sustituto		Original	Sustituto
C	Yellow	C	Yellow		
D	Blue	D	Blue		
MEDIA.P	Media.P	APP MEDIA	Media		
INTERNET @TV	Internet @TV	HOME SMART	Smart		
3D	3D	ECO 3D	3D		
D	D	E-MANUAL D.MENU	D. Menu		
P.SIZE	P. Size	PICTURE FORMAT	Format		
SUBT.	Subt.	AD SUBT	Subt		
<<	<<	<<	<<		
Pause	Pause	Pause	Pause		
>>	>>	>>	>>		
Rec	Rec	REC MODE	Rec		
Play	Play	PLAY MODE	Play		
Stop	Stop	Stop	Stop		