Original		Sustituto	
POWER	Power		Power
DVD	DVD	A	Red
TUNER	Tuner	B	Green
PORT	Port	C	Yellow
AUX	Aux	D	Blue
	Open / Close	ZOOM	Eject
TV/VIDEO	TV / Video	SEARCH TV/R	TV/R
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Sustituto	
REMAIN	Remain	-/-- GUIDE	Guide
CANCEL	Cancel	SHIFT + CLEAR EXIT	Shift + Exit
	I <<		I <<
STEP	Step	SHIFT +	Shift + Pause
PAUSE	Pause		Pause
	>>I		>>I
	<<		<<
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
	>>		>>
VOLUME	Volume +	VOL	Vol +
VOLUME	Volume -	VOL	Vol -
MUTE	Mute	MUTE	Mute
TUNING/CH	Tuning + / CH +	CH	Ch +
TUNING/CH	Tuning - / CH -	CH	Ch -
MENU	Menu	TOP MENU MENU	Menu
RETURN	Return	RETURN BACK	Back

Original		Sustituto	
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
AUDIO	Audio	SOUND DUAL	Dual
SUB TITLE	Subtitle	AD SUBT	Subt
EXIT	Exit	CLEAR EXIT	Exit
TUNER MEMORY SD/HD	SD/HD / Tuner Memory	FAV PRE-CH	Pre Ch
SLOW MO/ST	Mo/St / Slow	DISC NAV LIST	List
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
INFO	Info	DISPLAY INFO	Info
LOGO	Logo	PICTURE FORMAT	Format
SLEEP	Sleep	PROG SLEEP	Sleep
DIMMER	Dimmer	HOME SMART	Smart
REPEAT	Repeat	REPEAT TEXT	Text
V-SOUND V-H/P	V-Sound/V-H/P	ECO 3D	3D

Original		Sustituto	
AUDIO UPSCALE P.BASS	P. Bass / Audio Upscale	SETTINGS OPT	Options
S.VOL	S. Vol	APP MEDIA	Media
SOUND EDIT	Sound Edit	SHIFT + SOUND DUAL	Shift + Dual

Original		Sustituto	
POWER	Power		Power
TV/VIDEO	TV / Video	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
VOLUME +	Volume+	VOL +	Vol +
VOLUME −	Volume-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
TUNING/CH +	CH+	CH +	Ch +
TUNING/CH −	CH-	CH −	Ch -

Original		Sustituto	
MENU	Menu	TOP MENU MENU	Menu
RETURN	Return	RETURN BACK	Back
▲	Up	▲	Up
▶	Right	▶	Right
▼	Down	▼	Down
◀	Left	◀	Left
ENTER	Enter	OK	Ok