Original		Sustituto	
POWER	Power		Power
PLAY	Play	SLOW	Play / Slow
STILL/PAUSE	Still/Pause	STEP-FREEZE	Pause / Step / Freeze
STOP/LIVE	Stop/Live	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
REV	<<< / REV	TUNE-	<< / Tune-
FWD	>>> / FWD	TUNE+	>> / Tune+
F.ADV SKIP	I<< Skip/<<I	PRESET-	I<< / Preset-
F.ADV SKIP	F.ADV II>/Skip	PRESET+	>>I / Preset+
REC LIST DVD TITLE	DVD Title/Rec Li	TITLE SOUND	Sound / Title
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Subtitle	EQ SUBTITLE	Subtitle / EQ
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
REC MODE ZOOM	Zoom/Mode Rec	SIZE ZOOM	Zoom / Size
	AV Auto Rec	PROGRAM TV/RADIO	TV/Radio /
DIRECT	Direct	TOP MENU D.MENU	D.Menu / Top
ERASE C	C/Erase	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Sustituto	
TIME SHIFT	Timeshift	GOTO TEXT	Text / Goto
INPUT	Input	RDS AV INPUT	AV / Input / RDS
ORIGINAL/ PLAY LIST DVD MENU	DVD Menu/Original	HOME MENU	Menu / Home
	Up		Up
CH DISPLAY	CH Display	ANGLE INFO	Info / Angle
	Left		Left
SET/ ENTER	Set/Enter	OK	OK
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOL	Vol + Tv	VOL +	Vol +
START MENU	Start Menu	LIST SMART	Smart / List
CH	CH+	CH PAGE +	CH+ / Page+
	Vol - Tv	VOL -	Vol -
	Display/Back	MEDIA DISPLAY	Display / Media
	CH-	CH PAGE -	CH- / Page-

Original		Sustituto	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
ENT./AM/PM 100	100/ ENT. / AM/ F	GUIDE EPG	Guide / EPG / -/--
0	0	0	0
VCR PLUS+	VCR Plus	FAV MARKER	Fav / Marker / PC
COLOR B	Red/ B	NETFLIX SEARCH	Red / Netflix / Search
BUTTON C	Green/ C	APP REPEAT	Green / APP / Repeat
D	Yellow/ D	YouTube REPEAT A-B	Yellow / YouTube / Repeat
A	Blue/ A	Prime Video RANDOM	Blue / Prime Video / Random
POWER	Power Tv	SHIFT +	Shift + Power

Original		Sustituto	
REPLAY	Replay	SHIFT + SLOW	Shift + Play /
REC PAUSE	Rec Pause	SHIFT + STEP-FREEZE	Shift + Pause / Step /
REC STOP	Rec Stop	SHIFT + HOLD	Shift + Stop /
SKIP SEARCH	Skip Search	SHIFT + TUNE-	Shift + << /
SLOW	I > Slow	SHIFT + PRESET+	Shift + >>I / Preset+
	On Screen/Tamper	SHIFT + SIZE ZOOM	Shift + Zoom /
	Function	SHIFT + TOP MENU D.MENU	Shift + D. Menu / Top Menu
DUBBING	Dubbing	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
P IN P	P. I N P	SHIFT + GOTO TEXT	Shift + Text /
INPUT	Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
	Angle	SHIFT + ANGLE INFO	Shift + Info / Angle
	Chapter Mark/Connection	SHIFT + LIST SMART	Shift + Smart / List
CH	CH+ Tv	SHIFT + CH PAGE +	Shift + CH+ /
	CH- Tv	SHIFT + CH PAGE −	Shift + CH- /
DVD	DVD	SHIFT + DVD 2	Shift + 2
HDD	HDD	SHIFT + AUX-HDD 7	Shift + 7