Original		Sustituto	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
TV/RADIO	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
CH+	I<<	PRESET-	I<< / Preset-
CH-	>>I	PRESET+	>>I / Preset+
LAN/AUDIO	Lan/Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
TEXT	Text	GOTO TEXT	Text / Goto
MENU	Menu	HOME MENU	Menu / Home
CH+	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
V-	Left		Left

Original		Sustituto	
OK	OK	OK	OK
V+	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH-	Down		Down
	Recall	RETURN BACK	Back / Return
V+	Vol +	+ VOL	Vol +
AUTO	Auto	LIST SMART	Smart / List
CH+	CH+	+ CH PAGE	CH+ / Page+
V-	Vol -	VOL -	Vol -
CH-	CH-	CH PAGE -	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7

Original		Sustituto		Original	Sustituto
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
FAV	FAV	PC FAV MARKER	Fav / Marker / PC		
ZOOM	Red	NETFLIX SEARCH	Red / Netflix / Search		
LAN/AUDIO	Green	APP REPEAT	Green / APP / Repeat		
PLAY/PAUSE	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
TEXT	Blue	Prime Video RANDOM	Blue / Prime Video / Random		