Original		Sustituto	
	Power		Power
	AV Source	RDS AV INPUT	AV / Input / RDS
	Radio	PROGRAM TV/RADIO	TV/Radio /
	Audio Source	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
	TV / ARC	TIMER SLEEP	Sleep / Timer
	Main menu	HOME MENU	Menu / Home
	Disc Menu	TOP MENU D.MENU	D.Menu / Top
	Popup Menu	OPT-TOOLS SETUP	Setup / OPT /
	OSC / Program	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original		Sustituto	
9	9	BLUETOOTH 9	9
SEARCH	Search / Auto	LIST SMART	Smart / List
SEARCH	Search / Auto	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
0	0	HDMI - SAT 0	0
CLEAR	Clear / Delete	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Volume-	VOL −	Vol -
	Up		Up
	Volume+	+ VOL	Vol +
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Back	RETURN BACK	Back / Return
	Down		Down
	Mute	DIMMER MUTE	Mute / Dimmer
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
RESOLUTION ZOOM	Zoom / Resoluti	FORMAT PICTURE	Picture / Format
RESOLUTION ZOOM	Zoom / Resoluti	SIZE ZOOM	Zoom / Size

Original	Sustituto	Original	Sustituto
SUBTITLE STEREO MONO — Mono/Stereo / Subtitle	EQ SUBTITLE — Subtitle / EQ	C — Yellow	YouTube REPEAT A-B — Yellow / YouTube / Repeat
DISPLAY RDS — RDS / Display	MEDIA DISPLAY — Display / Media	D — Blue	Prime Video RANDOM — Blue / Prime Video / Random
LIPSYNC — LypSync	ANGLE INFO — Info / Angle		
SURROUND — Surround	SHIFT + SURROUND — Shift + Eject / Surround		
TONE — Tone	GOTO TEXT — Text / Goto		
SPEAKER LEVEL — Speaker Level	TITLE SOUND — Sound / Title		
Open / Close	SURROUND — Eject / Surround		
Stop	HOLD — Stop / Hold		
Play / Pause	SLOW — Play / Slow		
Play / Pause	STEP-FREEZE — Pause / Step / Freeze		
AUDIO — Audio	LANG I/II AUDIO — Audio / Lang I/II		
<< / Tune-	TUNE- — << / Tune-		
>> / Tune+	TUNE+ — >> / Tune+		
I<< / Preset-	PRESET- — I<< / Preset-		
>>I / Preset+	PRESET+ — >>I / Preset+		
A — Red	NETFLIX SEARCH — Red / Netflix / Search		
B — Green	APP REPEAT — Green / APP / Repeat		