Original		Sustituto	
	Power		Power
PROG	Prog	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
EJECT	Eject	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10+	10+	-/-- GUIDE	Guide
N/P	N/P	+ CH	Ch +
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Sustituto	
LANGUAGE	Language	SOUND DUAL	Dual
ANGLE	Angle	ECO 3D	3D
SETUP	Setup	SETTINGS OPT	Options
TIME	Time	TIMER AV	AV
TITLE	Title	D	Blue
MENU/PBC	Menu/PBC	TOP MENU MENU	Menu
	Up		Up
	Right		Right
	Down		Down
	Left		Left
ENTER	Enter	OK	Ok
FUNCTION	Function	APP MEDIA	Media
L/R	L/R	CH -	Ch -
STEP	Step	PICTURE FORMAT	Format
SLOW	Slow	CLEAR EXIT	Exit
RETURN	Return	RETURN BACK	Back
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject

Original		Sustituto		Original		Sustituto	
REPEAT	Repeat	REPEAT TEXT	Text				
A-B	A-B	DISC NAV LIST	List				
PLAY/PAUSE	Play	PLAY MODE	Play				
PLAY/PAUSE	Pause		Pause				
STOP	Stop		Stop				
REV	<<		<<				
FWD	>>		>>				
PREV	I <<		I <<				
NEXT	>>I		>>I				
VOL -	Vol -	VOL -	Vol -				
VOL +	Vol +	+ VOL	Vol +				
MUTE	Mute	MUTE	Mute				
U/D SCAN	U/D Scan	A	Red				
TFT ON/OFF	TFT On/Off	B	Green				
SPEAKER	Speaker	C	Yellow				