Original	Rechange	Original	Rechange
Power	Power	Left	Left
Mute	Mute / Dimmer	OK	OK
Play	Play / Slow	Right	Right
Stop	Stop / Hold	Down	Down
Rec	Rec / Rec Mode	Vol +	Vol +
<<	<< / Tune-	[-O-] / Active Control	Smart / List
>>	>> / Tune+	P+	CH+ / Page+
(O	Audio / Lang I/II	Vol -	Vol -
[<>]	Picture / Format	P-	CH- / Page-
Green/Timer	Sleep / Timer	1	1
>I <	D.Menu / Top	2	2
[1I 2]	Setup / OPT /	3	3
[≡]	Text / Goto	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i +]	Info / Angle	8	8

Original	Rechange	Original	Rechange
9	9	Right AMP	Shift + Right
Guide	Guide / EPG / -/--	Down AMP	Shift + Down
0	0	Vol + AMP	Shift + Vol +
P<P	Fav / Marker / PC	P+ AMP	Shift + CH+ /
Red	Red / Netflix / Search	Vol - AMP	Shift + Vol -
Green/Timer	Green / APP / Repeat	P- AMP	Shift + CH- /
Yellow/[ ]	Yellow / YouTube / Repeat	1 AMP	Shift + 1
Blue/[...]	Blue / Prime Video / Random	2 AMP	Shift + 2
Power AMP	Shift + Power	3 AMP	Shift + 3
Mute AMP	Shift + Mute / Dimmer	4 AMP	Shift + 4
<< AMP	Shift + << /	5 AMP	Shift + 5
>> AMP	Shift + >> /	6 AMP	Shift + 6
[≡] AMP	Shift + Text /	7 AMP	Shift + 7
Menu AMP	Shift + Menu /	8 AMP	Shift + 8
Up AMP	Shift + Up	9 AMP	Shift + 9
Left AMP	Shift + Left	Guide AMP	Shift + Guide / EPG / -/--
OK AMP	Shift + OK	0 AMP	Shift + 0

Original	Rechange	Original	Rechange
P<P AMP	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC		

Original	Rechange	Original	Rechange
Power	Power	P+	CH+ / Page+
Source	AV / Input / RDS	Vol -	Vol -
>>	>> / Tune+	P-	CH- / Page-
<<	<< / Tune-	1	1
Stop	Stop / Hold	2	2
Play	Play / Slow	3	3
Guide	Guide / EPG / -/--	4	4
[≡]	Text / Goto	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	[i+]	Info / Angle
>I<	D.Menu / Top	0	0
Menu	Menu / Home	P<P	Fav / Marker / PC
Vol +	Vol +	[1l2]	Setup / OPT /
Mute	Mute / Dimmer	[-O-]/Active Control	Smart / List

Original	Rechange	Original	Rechange
[<>]	FORMAT PICTURE Picture / Format		

Original	Rechange	Original	Rechange
Power	Power	OK	OK
Mute	Mute / Dimmer	Right	Right
Play	Play / Slow	Down	Down
Stop	Stop / Hold	Vol +	Vol +
Rec	Rec / Rec Mode	[-O-] / Active Control	Smart / List
<<	<< / Tune-	P+	CH+ / Page+
>>	>> / Tune+	Vol -	Vol -
(O	Audio / Lang I/II	P-	CH- / Page-
[<>]	Picture / Format	1	1
Green/Timer	Sleep / Timer	2	2
>I<	D.Menu / Top	3	3
[1I2]	Setup / OPT /	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i+]	Info / Angle	8	8
Left	Left	9	9

Original	Rechange	Original	Rechange
0	0	Left VCR	Shift + Left
P<P	Fav / Marker / PC	OK VCR	Shift + OK
Red	Red / Netflix / Search	Right VCR	Shift + Right
Green/Timer	Green / APP / Repeat	Down VCR	Shift + Down
Yellow/[ ]	Yellow / YouTube / Repeat	P+ VCR	Shift + CH+ /
Blue/[...]	Blue / Prime Video / Random	P- VCR	Shift + CH- /
Power VCR	Shift + Power	1 VCR	Shift + 1
Play VCR	Shift + Play /	2 VCR	Shift + 2
Stop VCR	Shift + Stop /	3 VCR	Shift + 3
Rec VCR	Shift + Rec / Rec Mode	4 VCR	Shift + 4
<< VCR	Shift + << /	5 VCR	Shift + 5
>> VCR	Shift + >> /	6 VCR	Shift + 6
>I < VCR	Shift + D.Menu / Top Menu	7 VCR	Shift + 7
Source VCR	Shift + AV / Input / RDS	8 VCR	Shift + 8
Menu VCR	Shift + Menu /	9 VCR	Shift + 9
Up VCR	Shift + Up	0 VCR	Shift + 0
[i+] VCR	Shift + Info / Angle	P<P VCR	Shift + Fav / Marker / PC

Original	Rechange	Original	Rechange
Power	Power	2	2
>>	>> / Tune+	3	3
<<	<< / Tune-	4	4
Stop	Stop / Hold	5	5
Play	Play / Slow	6	6
Guide	Guide / EPG / -/--	7	7
Up	Up	8	8
Left	Left	9	9
Right	Right	[i+]	Info / Angle
Down	Down	0	0
>I<	D. Menu / Top	P<P	Fav / Marker / PC
Vol +	Vol +		
Mute	Mute / Dimmer		
P+	CH+ / Page+		
Vol -	Vol -		
P-	CH- / Page-		
1	1		