Original		Rechange	
	Standby		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
MUTE	Mute	MUTE	Mute
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -

Original		Rechange	
P	PR+	+ CH	Ch +
P	PR-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Enter	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left
	Smart Hub	HOME SMART	Smart
A	Red	A	Red
B	Green	B	Green
C	Yellow	C	Yellow

Original		Rechange	
D	Blue	D	Blue
▶	Play	PLAY MODE ▶	Play
❚❚	Pause	❚❚	Pause
■	Stop	■	Stop
●	Rec	REC MODE ●	Rec
▶▶	>>	»	>>
▶▶❚	>>❚	»❚	>>❚
❚◀◀	❚<<	«❚	❚<<
◀◀	<<	«	<<
AD/SUBT.	AD/Subt.	AD SUBT	Subt
3D	3D	ECO 3D	3D
Family Story	Family Story	SEARCH TV/R	TV/R
HISTORY	History	PICTURE FORMAT	Format
SUPPORT	Support	SOUND DUAL	Dual
CAMERA	Camera	SHIFT + HOME SMART	Shift + Smart
CH LIST	CH List	DISC NAV LIST	List

Original	Rechange