Mandis shop

3GO 3GO-001

Original		Rechange	
POWER	Power	POWER	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PREV	I<</Prev	PRESET-	I<< / Preset-
HOME	Home	HOME MENU	Menu / Home
FR	<</FR	TUNE-	<< / Tune-
	>>I / Next	PRESET+	>>I / Preset+
SLOW	I>/Slow	PC FAV MARKER	Fav / Marker / PC
	>>/FF	TUNE+	>> / Tune+
NEXT RETURN	Return	RETURN BACK	Back / Return
	Up		Up
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
OK	OK	OK	OK
	Right		Right
VOL-	Vol -	VOL −	Vol -
	Down		Down
VOL+	Vol +	+ VOL	Vol +

Original		Rechange	
GOTO	Goto	GOTO TEXT	Text / Goto
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY/PAUSE	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
TV SYSTEM	Tv System	PROGRAM TV/RADIO	TV/Radio /
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
DISPLAY	i/Display	MEDIA DISPLAY	Display / Media
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
AV/YPBPR	AV/YPBPR	RDS AV INPUT	AV / Input / RDS
A-B	A-B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
SUBTITLE AA	aA/Subtitle	EQ SUBTITLE	Subtitle / EQ
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Green	APP REPEAT	Green / APP / Repeat

https://mandis.es/fr/3GO-3GO-001-telecommande-remplacement-pour-3GO-3GO-001.htm