Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
MEDIA PLAYER	Media Player	6	6
TV AUDIO	TV/Audio	7	7
AUX2	AUX2	8	8
TUNER	Tuner	9	9
iPod/USB	iPod/USB	-/-- GUIDE	Guide
CD	CD	0	0
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
ONLINE MUSIC	Online Music	APP MEDIA	Media
PHONO	Phono	HOME SMART	Smart
INTERNET RADIO	Internet/Radio	SEARCH TV/R	TV/R

Original		Rechange	
ECO	Eco	ECO 3D	3D
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
CH/PAGE	CH/Page+	+ CH	Ch +
CH/PAGE	CH/Page-	CH –	Ch -
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TUNE –	I<<Tune-	K<<	I<<
►/II	Play	PLAY MODE ►	Play

Original		Rechange	
►/II	Pause	II	Pause
TUNE + ►►I	Tune+/ >>I	>>I	>>I
1	Smart Select 1	E-MANUAL D.MENU	D. Menu
2	Smart Select 2	REPEAT TEXT	Text
3	Smart Select 3	ZOOM ⏏	Eject
4	Smart Select 4	TIMER AV	AV
MOVIE	Green/Movie	B	Green
MUSIC	Red/Music	A	Red
GAME	Blue/Game	D	Blue
PURE	Yellow/Pure	C	Yellow

Original	Rechange

Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
MEDIA PLAYER	Media Player	6	6
TV AUDIO	TV/Audio	7	7
AUX2	AUX2	8	8
TUNER	Tuner	9	9
iPod/USB	iPod/USB	-/-- GUIDE	Guide
CD	CD	0	0
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
ONLINE MUSIC	Online Music	APP MEDIA	Media
	Phono	HOME SMART	Smart
INTERNET RADIO	Internet Radio	SEARCH TV/R	TV/R

Original		Rechange	
CH/PAGE	CH/Page+	+ CH	Ch +
CH/PAGE	CH/Page-	CH –	Ch -
MUTE	Mute	MUTE	Mute
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
TUNE –	I<<Tune-		I<<
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
TUNE +	Tune+/>>I	>>I	>>I
	Smart Select 1	E-MANUAL D.MENU	D. Menu
	Smart Select 2	REPEAT TEXT	Text

Original	Rechange	Original	Rechange
Smart Select 3	ZOOM Eject		
Smart Select 4	TIMER AV		