Mandis shop

Panasonic N2QAYB000614

Original	Rechange	Original	Rechange
Power	Power	Option	Options
1	1	Back/Return	Back
2	2	Play/x1.3	Play
3	3	Pause	Pause
4	4	Stop	Stop
5	5	>>I	>>I
6	6	I <<	I <<
7	7	>>	>>
8	8	<<	<<
9	9	OK	Ok
0	0	Up	Up
Input Select	AV	Down	Down
Guide	Guide	Right/I >	Right
Exit	Exit	Left/ <I	Left
i/Status	Info	Red	Red
Function Menu	Menu	Green	Green
Direct Navigator/Pop-Up Menu	List	Yellow	Yellow

Original		Rechange	
	Blue	D	Blue
REC	Rec	REC MODE	Rec
VIERA CAST	Cast/Vieta	FAV PRE-CH	Pre Ch
S	S/Skipe	HOME SMART	Smart
TEXT	[≡]/Text	REPEAT TEXT	Text
STTL	[≡♦]/Sttl	AD SUBT	Subt
AD	AD	SHIFT + AD SUBT	Shift + Subt
DIRECT TV REC	Direct Tv Rec	SEARCH TV/R	TV/R
EXT LINK	Ext Link	PICTURE FORMAT	Format
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec
CHAPTER	Chapter	SOUND DUAL	Dual
TIME SLIP	Time Slip	ECO 3D	3D
MANU -10s	Manual Skip -10s	SHIFT + ◀	Shift + Left
PAGE CH	CH+	+ CH	Ch +
AL SKIP +60s	Manual Skip +60s	SHIFT + ▶	Shift + Right
CH	CH-	CH −	Ch -

Original		Rechange	
TV	Power Tv	SHIFT + ⏻	Shift + Power
INPUT AV	Av Input Tv	SHIFT + TIMER AV	Shift + AV
CH	CH+ Tv	SHIFT + + CH	Shift + Ch +
CH	CH- Tv	SHIFT + CH −	Shift + Ch -
VOL	Vol + Tv	+ VOL	Vol +
VOL	Vol - Tv	VOL −	Vol -
DEL	DEL	MUTE	Mute
DRIVE SELECT	Drive Select	APP MEDIA	Media