Original		Rechange	
I/⏻	Power	⏻	Power
DISPLAY	Display	DISPLAY INFO	Info
TIMER MENU	Timer Menu	TOP MENU MENU	Menu
SLEEP	Sleep	PROG SLEEP	Sleep
AUDIO IN	Audio In Function	A	Red
FM	FM Function	B	Green
CD	CD Function	C	Yellow
USB	USB Function	D	Blue
EQ	EQ	SOUND DUAL	Dual
FM MODE	FM Mode	SEARCH TV/R	TV/R
1	1 Tuner Memory Number	1	1
2	2 Tuner Memory Number	2	2
3	3 Tuner Memory Number	3	3
4	4 Tuner Memory Number	4	4
5	5 Tuner Memory Number	5	5
6	6 Tuner Memory Number	6	6
TUNER MEMORY	Tuner Memory	-/-- GUIDE	Guide

Original		Rechange	
PLAY MODE/ TUNING MODE	Play Mode / Tuning Mode	SHIFT + PLAY MODE ▶	Shift + Play
BASS BOOST	Bass Boost	AD SUBT	Subt
RETURN	Return	RETURN BACK	Back
REPEAT	Repeat	REPEAT TEXT	Text
VOLUME +	Volume+	+ VOL	Vol +
–	Volume-	VOL –	Vol -
▲	Up/Folder+	▲	Up
▼	Down/Folder-	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok
PRESET– ⏮	I<<</Preset-	⏮	I<<
⏸	Pause	⏸	Pause
PRESET+ ⏭	>>I/Preset+	⏭	>>I
TUNING– ◀◀	<<</Tuning-	◀◀	<<
▶	Play	PLAY MODE ▶	Play
TUNING+ ▶▶	>>/Tuning+	▶▶	>>

Original		Rechange	
	St op		St op
CLEAR	Cl ear	CLEAR EXIT	Exi t

Original	Rechange