Original		Rechange	
	Power		Power
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LANG.	Lang	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI - SAT 0	0
TXT	TXT	GOTO TEXT	Text / Goto
	Home	LIST SMART	Smart / List
	Home	TOP MENU D.MENU	D. Menu / Top
+ V	Vol +	+ VOL	Vol +

Original		Rechange	
P ^	P+	+ CH PAGE	CH+ / Page+
– V	Vol -	VOL –	Vol -
P v	P-	CH PAGE –	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
G	[G]	HOME MENU	Menu / Home
	Up		Up
i	i	ANGLE INFO	Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	<<	TUNE-	<< / Tune-
	Pause	STEP - FREEZE	Pause / Step / Freeze
	>>	TUNE+	>> / Tune+
	Rec	REC MODE	Rec / Rec Mode

Original		Rechange		Original	Rechange
	Play	SLOW	Play / Slow		
	Stop	HOLD	Stop / Hold		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		