Original	Rechange	Original	Rechange
Power	Power	TXT	Text
1	1	TV-G	Guide
2	2	Up	Up
3	3	Down	Down
4	4	Right	Right
5	5	Left	Left
6	6	OK	Ok
7	7	P+	Ch +
8	8	P-	Ch -
9	9	Vol +	Vol +
0	0	Vol -	Vol -
PIP/Audio	3D	Red/Image/I>	Red
[<>]	Format	Green/Timer	Green
?	Smart	Yellow/@	Yellow
Mute	Mute	Blue/Sound	Blue
Z/Disc Menu	Menu	Play	Play
i/OSD	Info	Pause	Pause

Original	Rechange	Original	Rechange
Stop	Stop		
<<	<<		
>>	>>		
I <	I <<		
>I	>>I		

Original	Rechange	Original	Rechange
Power	Power	Z/ Disc Menu	Menu
1	1	Up	Up
2	2	Down	Down
3	3	Right	Right
4	4	Left	Left
5	5	OK	Ok
6	6	P+	Ch +
7	7	P-	Ch -
8	8	Vol +	Vol +
9	9	Vol -	Vol -
0	0	Red/ Image/ I >	Red
PIP/ Audio	3D	Green/ Timer	Green
[<>]	Format	Yellow/ @	Yellow
?	Smart	Blue/ Sound	Blue
i / OSD	Info	Play	Play
TXT	Text	Pause	Pause
TV-G	Guide	Stop	Stop

Original	Rechange	Original	Rechange
TXT <<	<<		
TV-G >>	>>		
>I	>>I		
? I <	I <<		

Original	Rechange	Original	Rechange
Power	Power	Z/ Disc Menu	Menu
1	1	TV-G	Guide
2	2	Up	Up
3	3	Down	Down
4	4	Right	Right
5	5	Left	Left
6	6	OK	Ok
7	7	P+	Ch +
8	8	P-	Ch -
9	9	Vol +	Vol +
0	0	Vol -	Vol -
PIP/ Audio	3D	Red/ Image/ I >	Red
[<>]	Format	Green/ Timer	Green
?	Smart	Yellow/ @	Yellow
Mute	Mute	Blue/ Sound	Blue
i / OSD	Info	Play	Play
TXT	Text	Pause	Pause

Original	Rechange	Original	Rechange
St op	St op		
<<	<<		
>>	>>		
I <	I <<		
>I	>>I		

Original	Rechange	Original	Rechange
Power	Power	Z/ Disc Menu	Menu
1	1	P+	Ch +
2	2	P-	Ch -
3	3	Up	Up
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	OK	Ok
8	8	Vol +	Vol +
9	9	Vol -	Vol -
0	0	Red/ Image/ I >	Red
PIP/ Audio	3D	Green/ Timer	Green
[<>]	Format	Yellow/ @	Yellow
?	Smart	Blue/ Sound	Blue
i / OSD	Info	Play	Play
TXT	Text	Pause	Pause
TV-G	Guide	Stop	Stop

Original		Rechange		Original	Rechange
TXT	<<	<<	<<		
TV-G	>>	>>	>>		
?	| <	| <<	| <<		
	>|	>>|	>>|		