Original		Rechange	
RECEIVER	Power Recei ver		Power
ENTER	Enter Recei ver	OK	Ok
	Up Recei ver		Up
	Down Recei ver		Down
	Ri ght Recei ver		Ri ght
	Left Recei ver		Left
RETURN	Return Recei ver	RETURN BACK	Back
Q SETUP	Q/ Set up Recei ver	HOME SMART	Smart
AUDIO HOME	Home/ Audi o	APP MEDIA	Medi a
PLAY	Pl ay Recei ver	PLAY MODE	Pl ay
	I << Recei ver		I <<
	>>I Recei ver		>>I
	<< Recei ver		<<
	>> Recei ver		>>
	Pause Recei ver		Pause
	Stop Recei ver		Stop
1	1 Recei ver	1	1

Original		Rechange	
2	2 Recei ver	2	2
3	3 Recei ver	3	3
4	4 Recei ver	4	4
5	5 Recei ver	5	5
6	6 Recei ver	6	6
7	7 Recei ver	7	7
8	8 Recei ver	8	8
9	9 Recei ver	9	9
11 0	0/ 11 Recei ver	0	0
--/-- 10 +10 D.TUN DIMMER	+10/ - - / - - 10/ Di mm er/ D. Tun Recei ve	SHIFT + -/-- GUIDE	Shi ft + Gui de
12 CLR SLEEP	CLR/ Sl eep/ 12 Recei ver	FAV PRE-CH	Pre Ch
SEARCH MOVIE/TV A	Movi e Tv/ Red/ Search	A	Red
REPEAT MUSIC B	Musi c/ Green/ Repe at Recei ver	B	Green
RANDOM GAME C	Game/ Yel l ow/ Ran dom Recei ver	C	Yel l ow
MODE STEREO D	Ster eo/ Bl ue/ Mode Recei ver	D	Bl ue
VOL	Vol + Recei ver	VOL +	Vol +
VOL	Vol - Recei ver	VOL -	Vol -

Original		Rechange	
CH DISC	CH Disc/Album+ Receiver	CH +	Ch +
ALBUM	CH Disc/Album- Receiver	CH -	Ch -
TV	Power Tv	SHIFT +	Shift + Power
TV INPUT	Input Tv	TIMER AV	AV
CH DISC	CH+ Tv	SHIFT + CH +	Shift + Ch +
ALBUM	CH- Tv	SHIFT + CH -	Shift + Ch -
	Up Tv	SHIFT +	Shift + Up
ENTER	Enter Tv	SHIFT + OK	Shift + Ok
	Down Tv	SHIFT +	Shift + Down
	Right Tv	SHIFT +	Shift + Right
	Left Tv	SHIFT +	Shift + Left
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return Tv	SHIFT + RETURN BACK	Shift + Back
Q SETUP	Q/Setup Tv	SHIFT + HOME SMART	Shift + Smart
SEARCH MOVIE/TV A	Red Tv	SETTINGS OPT	Options
REPEAT MUSIC B	Green Tv	SOUND DUAL	Dual

Original		Rechange	
RANDOM GAME C	Yellow Tv	AD SUBT	Subt
MODE STEREO D	Blue Tv	SEARCH TV/R	TV/R
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
11 0	0/11 Tv	SHIFT + 0	Shift + 0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10 Tv	--/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	SHIFT + FAV PRE-CH	Shift + Pre Ch
VOL	Vol + Tv	SHIFT + SOUND DUAL	Shift + Dual
VOL	Vol - Tv	SHIFT + SETTINGS OPT	Shift + Options
AUX	AUX	REPEAT TEXT	Text

Original		Rechange		Original	Rechange
TV/CD	TV/ CD	PICTURE FORMAT	For mat		
CBL/SAT	CBL/ SAT	ECO 3D	3D		
FM	FM	SHIFT + AD SUBT	Shi f t + Subt		
NET	NET	SHIFT + APP MEDIA	Shi f t + Medi a		
PC	PC	SHIFT + SEARCH TV/R	Shi f t + TV/ R		
BD/DVD	BD/ DVD	SHIFT + REPEAT TEXT	Shi f t + Text		
USB	USB	SHIFT + TIMER AV	Shi f t + AV		

Original		Rechange	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Original		Rechange	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD	B	Green
RANDOM GAME C	Game/Yellow/Random BD/DVD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
D.TUN DIMMER	+10/--/--10/D.Tuning Dimmer BD/DVD	GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Original		Rechange
CBL/SAT	CBL/SAT	REPEAT TEXT Text
VOL	Vol + Receiver	+ VOL Vol +
VOL	Vol - Receiver	VOL − Vol -
SOURCE	Power CBL/SAT	SHIFT + Shift + Power
CH DISC	CH Disc/Album+ CBL/SAT	+ CH Ch +
ALBUM	CH Disc/Album- CBL/SAT	CH − Ch -
MENU PREV CH	Menu/Prev CH CBL/SAT	SHIFT + TOP MENU MENU Shift + Menu
TOP MENU GUIDE	Top Menu/Guide CBL/SAT	SHIFT + SETTINGS OPT Shift + Options
RETURN	Return CBL/SAT	SHIFT + RETURN BACK Shift + Back
Q SETUP	Q/Setup	SHIFT + HOME SMART Shift + Smart
	Up CBL/SAT	SHIFT + Shift + Up
ENTER	Enter CBL/SAT	SHIFT + OK Shift + Ok
	Down CBL/SAT	SHIFT + Shift + Down
	Right CBL/SAT	SHIFT + Shift + Right
	Left CBL/SAT	SHIFT + Shift + Left
II	Pause CBL/SAT	SHIFT + II Shift + Pause
■	Stop CBL/SAT	SHIFT + ■ Shift + Stop

Original		Rechange
◀◀	<< CBL/SAT	SHIFT + CH − Shift + Ch -
▶▶	>> CBL/SAT	SHIFT + + CH Shift + Ch +
PLAY	Play CBL/SAT	ECO 3D 3D
SEARCH MOVIE/TV A	Movie Tv/Red/Search	SOUND DUAL Dual
REPEAT MUSIC B	Music/Green/Repeat CBL/SAT	AD SUBT Subt
RANDOM GAME C	Game/Yellow/Random CBL/SAT	TIMER AV AV
MODE STEREO D	Stereo/Blue/Mode CBL/SAT	PICTURE FORMAT Format
1	1 CBL/SAT	SHIFT + 1 Shift + 1
2	2 CBL/SAT	SHIFT + 2 Shift + 2
3	3 CBL/SAT	SHIFT + 3 Shift + 3
4	4 CBL/SAT	SHIFT + 4 Shift + 4
5	5 CBL/SAT	SHIFT + 5 Shift + 5
6	6 CBL/SAT	SHIFT + 6 Shift + 6
7	7 CBL/SAT	SHIFT + 7 Shift + 7
8	8 CBL/SAT	SHIFT + 8 Shift + 8
9	9 CBL/SAT	SHIFT + 9 Shift + 9
0 11	0/11 CBL/SAT	SHIFT + 0 Shift + 0

Original	Rechange	Original	Rechange
BD/DVD BD/ DVD	SEARCH TV/R TV/ R		

Original		Rechange	
SOURCE	Power TV/CD		Power
CH DISC	CH/Disc+ TV/CD	CH	Ch +
ALBUM	CH/Disc TV/CD	CH	Ch -
RETURN	Return TV/CD	RETURN BACK	Back
Q SETUP	Q/Setup TV/CD	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
	Up TV/CD		Up
	Down TV/CD		Down
	Right TV/CD		Right
	Left TV/CD		Left
ENTER	Enter TV/CD	OK	Ok
	I<< TV/CD		I<<
	>>I TV/CD		>>I
	<< TV/CD		<<
	>> TV/CD		>>
PLAY	Play TV/CD	PLAY MODE	Play
	Pause TV/CD		Pause

Original		Rechange	
	Stop TV/CD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat TV/CD	B	Green
RANDOM GAME C	Game/Yellow/Random TV/CD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode TV/CD	D	Blue
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9
11 0	0/11 TV/CD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer TV/CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

TV/CD

Original		Rechange		Original		Rechange	
VOL	Vol + Recei ver	+ VOL	Vol +				
VOL	Vol - Recei ver	VOL −	Vol -				
TV/CD	TV/ CD	SEARCH TV/R	TV/ R				

Original		Rechange	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	VOL	Vol +
VOL	Vol - Zone 2	VOL	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH	Ch +
ALBUM	CH Disc/Album- Zone 2	CH	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
	Right Zone 2		Right
	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
Q SETUP	Q/Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Home/Audio Zone	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
PLAY	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Original		Rechange	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Zone 2	B	Green
RANDOM GAME C	Game/Yellow/Random Zone 2	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
0 11	0/11 Zone 2	0	0

Original	Rechange	Original	Rechange
+10/- - /- - 10/D. Tu Dimmer Zone 2	Guide		
CLR/Sleep/12	Pre Ch		