Mandis shop

Sony RM-DC345

Original		Rechange	
CONTINUE	Continue Play	HOME SMART	Smart
SHUFFLE	Shuffle Play Mod	SOUND DUAL	Dual
PROGRAM	Program Play	PROG SLEEP	Sleep
REPEAT	Repeat	REPEAT TEXT	Text
TIME	Time	TIMER AV	AV
DISC SKIP	Disc Skip	DISPLAY INFO	Info
▶	Play	PLAY MODE ▶	Play
❚❚	Pause	❚❚	Pause
■	Stop	■	Stop
AMS ▶▶❚	AMS >>I	▶▶❚	>>I
AMS ❚◀◀	I << AMS	❚◀◀	I <<
▶▶	>>	▶▶	>>
◀◀	<<	◀◀	<<
+ ANALOG OUT LEVEL	Analog Out	+ VOL	Vol +
ANALOG OUT LEVEL −	Analog Out Level	VOL −	Vol -

Original	Rechange

https://mandis.co.fr/Sony-105415-69-telecommande-remplacement-pour-Sony-RM-DC345-148572.htm