| Original | | Rechange | |
|---|---|---|---|
| PP | PP | RETURN BACK | Back / Return |
| | Power | | Power |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| P<P | P<P | PC FAV MARKER | Fav / Marker / PC |
| 0 | 0 | HDMI - SAT 0 | 0 |
| -- | -- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| M | Menu [M] | HOME MENU | Menu / Home |
| i | Info [i] | ANGLE INFO | Info / Angle |
| I-II | I-II | LANG I/II AUDIO | Audio / Lang I/II |

| Original | | Rechange | |
|---|---|---|---|
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Left | | Left |
| | Up | | Up |
| | Right | | Right |
| OK | OK | OK | OK |
| | Down | | Down |
| V - | V - | VOL − | Vol - |
| V + | V + | + VOL | Vol + |
| P - | P - | CH PAGE − | CH- / Page- |
| P + | P + | + CH PAGE | CH+ / Page+ |
| SOUND | Red / Sound | NETFLIX SEARCH | Red / Netflix / Search |
| SOUND | Red / Sound | TITLE SOUND | Sound / Title |
| PICTURE | Green / Picture | APP REPEAT | Green / APP / Repeat |
| PICTURE | Green / Picture | FORMAT PICTURE | Picture / Format |
| FEATURE | Yellow / Feature | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| INSTALL | Blue / Install | Prime Video RANDOM | Blue / Prime Video / Random |
| | Text | GOTO TEXT | Text / Goto |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| [≡o] | Sleep / Timer | | |
| Hold | Stop / Hold | | |
| [≡X] | Exit / Cancel / Clear | | |
| Mix / PIP Swap | Smart / List | | |
| PIP / Size | Zoom / Size | | |
| PIP Down / [≡?] | I<< / Preset- | | |
| PIP Up / Index | >>I / Preset+ | | |
| [TV] | TV/Radio / | | |
| [AV] | AV / Input / RDS | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |