Original		Rechange	
	Power		Power
DIRECT TV REC	Direct Tv Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode
AV LINK/ TV ASPECT	Tv Aspect/AV Lin	FORMAT PICTURE	Picture / Format
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
TRACKING/V-LOCK +	Tracking/V-Lock+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
-	Tracking/V-Lock-	CH PAGE -	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol +	+ VOL	Vol +
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS

Original		Rechange	
0	0	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
–	Vol -	VOL –	Vol -
LIBRARY/SEARCH	Library/Search	NETFLIX SEARCH	Red / Netflix / Search
INDEX	I<< Index	PRESET-	I<< / Preset-
INDEX	Index >>I	PRESET+	>>I / Preset+
ShowView	ShowView	ANGLE INFO	Info / Angle
STILL ALBUM	Still Album	LIST SMART	Smart / List
REPLAY	Replay	RETURN BACK	Back / Return
II/▶	Pause/Step	STEP-FREEZE II	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
MENU	Menu	HOME MENU	Menu / Home
▲	Up	▲	Up
▶	Play	SLOW ▶	Play / Slow
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
◀	Left	◀	Left
◀◀	<<	TUNE- ◀◀	<< / Tune-

Original		Rechange	
OK	OK	OK	OK
Right	Right		Right
>>	>> / Tune+	TUNE+	
Down	Down		Down
Stop	Stop / Hold	HOLD	
Prog. / Check Up	Shift + Up	SHIFT +	
Date+	Shift + Right	SHIFT +	
On+	Shift + Vol +	SHIFT +	VOL
Off +	Shift + CH+ /	SHIFT +	CH PAGE
Prog. / Check Down	Shift + Down	SHIFT +	
Date-	Shift + Left	SHIFT +	
On-	Shift + Vol -	SHIFT +	VOL
Off -	Shift + CH- /	SHIFT +	CH PAGE
Prog. Check	TV/ Radio /	PROGRAM TV/ RADIO	
Cancel	Shift + Exit / Cancel / Clear	SHIFT +	CLEAR EXIT CANCEL
SP/ LP/ EP	Setup / OPT /	OPT-TOOLS SETUP	
Timer	Sleep / Timer	TIMER SLEEP	

Original		Rechange	
I - Timer	Shift + Sleep / Timer	SHIFT +	TIMER SLEEP
Audio	Audio / Lang I/II	LANG I/II AUDIO	
OSD/ Display	Display / Media	MEDIA DISPLAY	
Reset	Green / APP / Repeat	APP REPEAT	

Original		Rechange	
	Power		Power
AV LINK/ TV ASPECT	Tv Aspect/AV Lin	FORMAT PICTURE	Picture / Format
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
CKING/V-LOCK +	Tracking/V. Lock+	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
−	Tracking/V. Lock-	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol +	+ VOL	Vol +
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0

Original		Rechange	
-/--	-/--	GUIDE EPG -/--	Guide / EPG / -/--
−	Vol -	VOL −	Vol -
^	Prog./Check Up	▲	Up
^	Red	NETFLIX SEARCH	Red / Netflix / Search
+ DATE	Green	APP REPEAT	Green / APP / Repeat
+ DATE	Date+	▶	Right
+ ON	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
+ ON	On+	SHIFT + + VOL	Shift + Vol +
+ OFF	Blue	Prime Video RANDOM	Blue / Prime Video / Random
+ OFF	Off +	SHIFT + + CH PAGE	Shift + CH+ /
PROG./CHECK	Prog./Check Down	▼	Down
DATE −	Date-	◀	Left
ON −	On-	SHIFT + VOL −	Shift + Vol -
OFF − TIMER	Off -	SHIFT + CH PAGE −	Shift + CH- /