Original		Rechange	
	Power		Power
	1	1	1
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0	0	0
RECALL	Recall	RETURN BACK	Back
STILL	Still	II	Pause
	TV / Input	TIMER AV	AV
MULTIMEDIA	Multimedia	APP MEDIA	Media
ZOOM -	Zoom -	SHIFT +	Shift + Down
ZOOM +	Zoom +	SHIFT +	Shift + Up

Original		Rechange	
	Up / PR +		Up
	Up / PR +	+ CH	Ch +
	Down / PR -		Down
	Down / PR -	CH –	Ch -
	Right / Vol +		Right
	Right / Vol +	+ VOL	Vol +
	Left / Vol -		Left
	Left / Vol -	VOL –	Vol -
MENU	Menu	TOP MENU MENU	Menu
MENU	Menu	OK	Ok
PREV PR	Prev PR	FAV PRE-CH	Pre Ch
SCREEN SIZE	Screen Size	ECO 3D	3D
	Mute	MUTE	Mute
SLEEP	Sleep	PROG SLEEP	Sleep
	[≡]	REPEAT TEXT	Text
	[≡?]	HOME SMART	Smart
	[≡X]	CLEAR EXIT	Exit

Original	Rechange	Original	Rechange
[≡↕]	ZOOM ⏏ Eject		
[≡◉]	SEARCH TV/R TV/R		
[≡□]	■ Stop		
PICT MODE Pic Mode / [/ ≡	PICTURE FORMAT Format		
SOUND MODE Sound Mode / [≡	SOUND DUAL Dual		
Red	A Red		
Green	B Green		
Yellow	C Yellow		
I-II Blue / I-II	D Blue		
I-II Blue / I-II	SHIFT + SOUND DUAL Shift + Dual		

Original		Rechange	
	Power		Power
	1	1	1
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0	0	0
	TV / Input	TIMER AV	AV
	Up / PR +		Up
	Up / PR +	+ CH	Ch +
	Down / PR -		Down
	Down / PR -	CH −	Ch -
	Menu	TOP MENU MENU	Menu

Original		Rechange	
	Menu	OK	Ok
F.R/SLOW	<< FR / Slow		<<
PLAY	Play	PLAY MODE	Play
F.F/SLOW	>> FF / Slow		>>
STOP	Stop		Stop
PREV	I<< Prev		I<<
OPEN/ CLOSE	Open / Close	ZOOM	Eject
NEXT	>>I Next		>>I
PAUSE	Pause		Pause

Original		Rechange	
	Power		Power
	1	1	1
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0	0	0
	Up / PR +		Up
	Up / PR +	+ CH	Ch +
	Down / PR -		Down
MENU	Menu	OK	Ok
	Down / PR -	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu

Original		Rechange	
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
I-II	Blue / I-II	D	Blue
I-II	Blue / I-II	SOUND DUAL	Dual