| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | i | DISPLAY INFO | Info |
| PICTURE SIZE | Picture Size | PICTURE FORMAT | Format |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| INPUT SELECT | Input Select | TIMER AV | AV |
| GUIDE EPG | Guide (EPG) | -/-- GUIDE | Guide |
| + | Vol + | + VOL | Vol + |
| – | Vol - | VOL – | Vol - |

| Original | | Rechange | |
|---|---|---|---|
| | Mute | MUTE | Mute |
| FREEZE | Freeze | SHIFT + II | Shift + Pause |
| P↔P | P↔P | FAV PRE-CH | Pre Ch |
| + P | P + | + CH | Ch + |
| P – | P - | CH – | Ch - |
| MENU | Menu | TOP MENU MENU | Menu |
| RETURN | Return | RETURN BACK | Back |
| ▲ | Up | ▲ | Up |
| ◄ | Left / ◁ | ◄ | Left |
| ENTER/ CH LIST | Enter / CH List | OK | Ok |
| ENTER/ CH LIST | Enter / CH List | DISC NAV LIST | List |
| ► | Right / I> | ► | Right |
| ▼ | Down | ▼ | Down |
| AUDIO I/II | Audio I/II | SOUND DUAL | Dual |
| [....] | [....] | AD SUBT | Subt |
| | Red | A | Red |
| | Green | B | Green |

| Original | | Rechange | |
|---|---|---|---|
| | Yellow | C | Yellow |
| | Blue | D | Blue |
| | I<< / [≡●] | K< | I<< |
| | >>I / [≡?] | >> | >>I |
| | << / [≡▯] | << | << |
| | >> / [≡↕] | >> | >> |
| | Stop | ■ | Stop |
| | Pause | II | Pause |
| | [≡] | REPEAT TEXT | Text |
| | Play | PLAY MODE ▶ | Play |
| TV | TV | SEARCH TV/R | TV/R |
| MEDIA | Media | APP MEDIA | Media |
| PLAY MODE REC LIST | Play Mode / Rec List | HOME SMART | Smart |
| PLAY MODE REC LIST | Play Mode / Rec List | SHIFT + PLAY MODE ▶ | Shift + Play |
| T-REC | T-REC | ECO 3D | 3D |
| REC | REC | REC MODE ● | Rec |
| | | | |

| Original | Rechange |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |