Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL / SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	Aux	5	5
MEDIA PLAYER	Media Player	6	6
iPod/USB	iPod / USB	7	7
TV AUDIO	TV / Audio	8	8
TUNER	Tuner	9	9
NETWORK	Network	-/-- GUIDE	Guide
MEDIA SERVER	Media Server	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
CHANNEL +	Channel +	+ CH	Ch +
CHANNEL –	Channel -	CH –	Ch -
PAGE	Page+	SHIFT + + CH	Shift + Ch +

Original		Rechange	
PAGE	Page-	SHIFT + CH –	Shift + Ch -
MOVIE	Green / Movie	B	Green
MUSIC	Red / Music	A	Red
GAME	Blue / Game	D	Blue
PURE	Yellow / Pure	C	Yellow
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
OPTION	Option	TOP MENU MENU	Menu
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back
SETUP	Setup	HOME SMART	Smart
VOLUME	Volume+	+ VOL	Vol +
VOLUME	Volume-	VOL –	Vol -

Original		Rechange		Original	Rechange
1	FAV Station 1	SHIFT + 1	Shift + 1		
2	FAV Station 2	SHIFT + 2	Shift + 2		
3	FAV Station 3	SHIFT + 3	Shift + 3		
MUTE	Mute	MUTE	Mute		
TUNE +	>>I / Tune+	>>I	>>I		
– TUNE	I << / Tune-	I <<	I <<		
▶	Play	PLAY MODE ▶	Play		
II	Pause	II	Pause		