Original	Rechange
Mute	DIMMER MUTE — Mute / Dimmer
Power	Power
(↔)	LANG I/II AUDIO — Audio / Lang I/II
TV	PROGRAM TV/RADIO — TV/Radio /
_/	TITLE SOUND — Sound / Title
[#]→	FORMAT PICTURE — Picture / Format
[.≡]	GOTO TEXT — Text / Goto
[≡+]	SHIFT + HOLD ■ — Shift + Stop /
[≡♦]	SHIFT + SIZE ZOOM — Shift + Zoom /
[≡x]◷	RETURN BACK — Back / Return
[≡?][+]	TIMER SLEEP — Sleep / Timer
1	TV 1 — 1
2	DVD 2 — 2
3	CD-STB 3 — 3
[≡i]	ANGLE INFO — Info / Angle
4	VIDEO 4 — 4
5	TAPE 5 — 5

Original	Rechange
6	TUNER 6 — 6
A/B	SHIFT + YouTube REPEAT A-B — Shift + Yellow / YouTube /
7	AUX-HDD 7 — 7
8	USB 8 — 8
9	BLUETOOTH 9 — 9
OUTPUT	RDS AV INPUT — AV / Input / RDS
-/--	-/-- GUIDE EPG — Guide / EPG / -/--
0	HDMI-SAT 0 — 0
C	CLEAR EXIT CANCEL — Exit / Cancel / Clear
IN 123	TOP MENU D.MENU — D.Menu / Top
1- TP OFF	PC FAV MARKER — Fav / Marker / PC
C00	OPT-TOOLS SETUP — Setup / OPT /
2- TP ON	SHIFT + PC FAV MARKER — Shift + Fav / Marker / PC
Vol +	+ VOL — Vol +
Prog+	+ CH PAGE — CH+ / Page+
Vol -	VOL − — Vol -
PROGR	CH PAGE − — Prog- / CH- / Page-

Original	Rechange
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
→>	Display / Media
-[<>]	Left
[<>]+	Right
♦	Zoom / Size
(*)	Menu / Home
→←	Smart / List
[II··]	OK
[II··]+	Up
[...]	Subtitle / EQ
Contrast+	>>I / Preset+
Brightness+	Shift + Right
[II··]-	Down
Prog+ Down	Shift + CH+ / Page+

Original	Rechange
Contrast-	I<< / Preset-
Brightness-	Shift + Left
Power Down	Shift + Power
Prog- Down	Shift + CH- /
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+
Stop	Stop / Hold
Pause	Pause / Step / Freeze

Original	Rechange	Original	Rechange
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
>>	>> / Tune+		
Play	Play / Slow		
<<	<< / Tune-		

Original	Rechange	Original	Rechange
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
>>	>> / Tune+		
Play	Play / Slow		
<<	<< / Tune-		

Original	Rechange	Original	Rechange
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		