Mandis shop

T4

Original		Rechange	
	Power		Power
AUX	AUX	A	Red
DIGITAL	Digital	D	Blue
	Bluetooth	B	Green
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
▶▶I	>>I	>>I	>>I
I◀◀	I <<	I<<	I <<
◀+	Vol +	+ VOL	Vol +
◀−	Vol -	VOL −	Vol -

Original	Rechange

https://mandis-shop.com/fr/GRATUIT/1614-874-telecommande-de-remplacement-pour-GRATUIT-T4.html