Original		Rechange	
	Power		Power
	[i+]	DISPLAY INFO	Info
AV1	AV1	TIMER AV	AV
AV1	AV1	SHIFT + 1	Shift + 1
AV2	Rec/AV2	SHIFT + 2	Shift + 2
AV2	Rec/AV2	REC MODE	Rec
AV3	Stop/AV3	SHIFT + 3	Shift + 3
AV3	Stop/AV3		Stop
AV4	Play/AV4	SHIFT + 4	Shift + 4
AV4	Play/AV4	PLAY MODE	Play
AV5	AV5	SHIFT + 5	Shift + 5
AV5	AV5	SHIFT + TIMER AV	Shift + AV
AV6	Pause/AV6	SHIFT + 6	Shift + 6
AV6	Pause/AV6		Pause
RGB1	<<</RGB1	SHIFT + 7	Shift + 7
RGB1	<<</RGB1		<<
RGB2	>>/RGB2		>>

Original		Rechange	
RGB2	>>/RGB2	SHIFT + 8	Shift + 8
MENU	Menu	TOP MENU MENU	Menu
	[>I<]/Recall	FAV PRE-CH	Pre Ch
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
S.MODE	♪/S.Mode	SHIFT + SOUND DUAL	Shift + Dual
P.MODE	(I)/P.Mode	SHIFT + PICTURE FORMAT	Shift + Format
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
I/II	I/II	SOUND DUAL	Dual
	Mute	MUTE	Mute
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
1	1	1	1

Original		Rechange	
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
2-4-12	[I]/2-4-12	RETURN BACK	Back
	[I≡]	-/-- GUIDE	Guide
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	[≡i]	SETTINGS OPT	Options
	[≡x]	SEARCH TV/R	TV/R

Original		Rechange	
SLIDE SHOW	[...]/Slide Show	AD SUBT	Subt
ROTATE	[≡?]/Rotate	ECO 3D	3D
	[≡]	REPEAT TEXT	Text
	[<>]	PICTURE FORMAT	Format
SWIVEL	Swivel	HOME SMART	Smart
PHOTO	Photo	APP MEDIA	Media

Original		Rechange		Original	Rechange
	Power		Power		
OK	OK	OK	Ok		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
MENU	Menu	TOP MENU MENU	Menu		
AV3	Stop		Stop		
AV4	Play	PLAY MODE	Play		
AV6	Pause		Pause		
RGB1	<<		<<		
RGB2	>>		>>		
P	P+	CH	Ch +		
P	P-	CH	Ch -		

Original		Rechange	
	Power		Power
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7

Original		Rechange	
	8		8
	9		9
	0		0