| Original | | Rechange | |
|---|---|---|---|
| ⏻/I | Power | ⏻ | Power |
| KEYSTONE 6 | Keystone/6 | FORMAT PICTURE | Picture / Format |
| AUTO SETUP | Auto Setup | OPT-TOOLS SETUP | Setup / OPT / |
| COMPUTER 1 | Computer 1 | NETFLIX SEARCH | Red / Netflix / Search |
| COMPUTER 1 | Computer 1 | PC FAV MARKER | Fav / Marker / PC |
| COMPUTER 2 | Computer 2 | APP REPEAT | Green / APP / Repeat |
| HDMI | HDMI | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| HDMI | HDMI | HDMI - SAT 0 | 0 |
| VIDEO | Video | Prime Video RANDOM | Blue / Prime Video / Random |
| VIDEO | Video | SHIFT + VIDEO 4 | Shift + 4 |
| S-VIDEO | S-Video | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| ▲ | Up | ▲ | Up |
| ◀ | Left | ◀ | Left |
| ENTER | Enter | OK | OK |
| ▶ | Right | ▶ | Right |
| ▼ | Down | ▼ | Down |
| MENU | Menu | HOME MENU | Menu / Home |

| Original | | Rechange | |
|---|---|---|---|
| DEFAULT | Default | MEDIA DISPLAY | Display / Media |
| FUNCTION | Function | LIST SMART | Smart / List |
| RETURN | Return | RETURN BACK | Back / Return |
| FREEZE | Freeze | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| ID SET | ID Set | SLOW ▶ | Play / Slow |
| ID ALL | ID All | HOLD ■ | Stop / Hold |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| D.ZOOM+ 1 | D. Zoom+/1 | + CH PAGE | CH+ / Page+ |
| D.ZOOM+ 1 | D. Zoom+/1 | TV 1 | 1 |
| VOL+ 2 | Vol +/2 | DVD 2 | 2 |
| VOL+ 2 | Vol +/2 | + VOL | Vol + |
| P-TIMER 3 | P. Timer/3 | TIMER SLEEP | Sleep / Timer |
| P-TIMER 3 | P. Timer/3 | CD-STB 3 | 3 |
| AV MUTE | AV Mute | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer |
| D.ZOOM− 4 | D. Zoom-/4 | CH PAGE − | CH- / Page- |
| D.ZOOM− 4 | D. Zoom-/4 | VIDEO 4 | 4 |
| VOL− 5 | Vol -/5 | TAPE 5 | 5 |

| Original | | Rechange | |
|---|---|---|---|
| VOL− 5 | Vol - / 5 | VOL − | Vol - |
| KEYSTONE 6 | Keystone/ 6 | TUNER 6 | 6 |

| Original | Rechange |
|---|---|
| | |