Original		Rechange	
STANDBY	Standby	SHIFT +	Shift + Power
POWER	Power		Power
MULTI	Multi	GUIDE EPG	Guide / EPG / -/--
V-AUX	V-AUX	AUX-HDD 7	7
PHONO	Phono	SHIFT +	TITLE SOUND Shift + Sound / Title
DOCK	Dock	SIZE ZOOM	Zoom / Size
BD HD DVD	BD/HD DVD	SHIFT +	TAPE 5 Shift + 5
DVD	DVD	DVD 2	2
CD	CD	CD-STB 3	3
MD CD-R	MD/CD-R	GOTO TEXT	Text / Goto
CBL SAT	CBL/SAT	SHIFT +	PROGRAM TV/RADIO Shift + TV/Radio / Program
TV	TV	PROGRAM TV/RADIO	TV/Radio /
DVR	DVR	TOP MENU D.MENU	D.Menu / Top
VCR	VCR	VIDEO 4	4
TUNER	Tuner	TUNER 6	6
USB	USB	USB 8	8
1	System Memory	SHIFT +	TV 1 Shift + 1

Original		Rechange	
2	System Memory	SHIFT +	DVD 2 Shift + 2
3	System Memory	SHIFT +	CD-STB 3 Shift + 3
4	System Memory	SHIFT +	VIDEO 4 Shift + 4
TITLE BAND	Title	TITLE SOUND	Sound / Title
MENU SRCH MODE	Menu	HOME MENU	Menu / Home
VOLUME +	Vol +	+ VOL	Vol +
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶ A-E	Right	▶	Right
▼	Down	▼	Down
–	Vol -	VOL –	Vol -
RETURN MEMORY	Return	RETURN BACK	Back / Return
PARAMETER DISPLAY	Display	MEDIA DISPLAY	Display / Media
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CLASSICAL 1	1/Classical	TV 1	1
LIVE/CLUB 2	2/Live Club	SHIFT +	MEDIA DISPLAY Shift + Display / Media

Original		Rechange		Original	Rechange
ENTERTAIN 3	3/ Entertain	LIST SMART	Smart / List		
MOVIE 4	4/ Movie	SHIFT + LIST SMART	Shift + Smart / List		
STEREO 5	5/ Stereo	TAPE 5	5		
ENHANCER 6	6/ Enhancer	SHIFT + TUNER 6	Shift + 6		
SUR. DECODE 7	7/ Sur. Decode	SHIFT + AUX - HDD 7	Shift + 7		
STRAIGHT 8	8/ Straight	SHIFT + USB 8	Shift + 8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
EXTD SUR. +10	+10/ EXTD Sur.	PC FAV MARKER	Fav / Marker / PC		
PURE DIRECT ENT	ENT/ Pure Direct	SHIFT + OK	Shift + OK		
INFO +	Info	ANGLE INFO	Info / Angle		
LEVEL +	Level	OPT-TOOLS SETUP	Setup / OPT /		
SLEEP MUTE	Sleep	TIMER SLEEP	Sleep / Timer		
AUDIO SEL AUDIO	Audio/ Audio Se	LANG I/II AUDIO	Audio / Lang I/II		
3D DSP	3D DSP	FORMAT PICTURE	Picture / Format		

Original		Rechange	
POWER	Power		Power
TITLE / BAND	Title	TITLE / SOUND	Sound / Title
MENU / SRCH MODE	Menu	HOME / MENU	Menu / Home
VOLUME +	Vol +	+ / VOL	Vol +
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶ A-E	Right	▶	Right
▼	Down	▼	Down
–	Vol -	VOL –	Vol -
RETURN / MEMORY	Return	RETURN / BACK	Back / Return
PARAMETER / DISPLAY	Display	MEDIA / DISPLAY	Display / Media
MUTE	Mute	DIMMER / MUTE	Mute / Dimmer
REC	Rec	REC MODE	Rec / Rec Mode
❚❚	Pause	STEP - FREEZE / ❚❚	Pause / Step / Freeze
▶	Play	SLOW / ▶	Play / Slow
■	Stop	HOLD / ■	Stop / Hold

Original		Rechange	
◀◀	<<	TUNE- / ◀◀	<< / Tune-
▶▶ / EON	>>	TUNE+ / ▶▶	>> / Tune+
⏮ / MODE – PTY S	I <<	PRESET- / ⏮	I << / Preset-
⏭ / SEEK – START	>>I	PRESET+ / ⏭	>>I / Preset+
CLASSICAL 1	1	TV 1	1
LIVE/CLUB 2	2	DVD 2	2
ENTERTAIN 3	3	CD - STB 3	3
MOVIE 4	4	VIDEO 4	4
STEREO 5	5	TAPE 5	5
ENHANCER 6	6	TUNER 6	6
SUR. DECODE 7	7	AUX - HDD 7	7
STRAIGHT 8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
EXTD SUR. +10	+10	-/-- / GUIDE EPG	Guide / EPG / -/--
PURE DIRECT ENT	ENT	SHIFT + OK	Shift + OK
AUDIO SEL / AUDIO	Audio	LANG I/II / AUDIO	Audio / Lang I/II

Original		Rechange	
POWER	Power		Power
TITLE BAND	Band	TOP MENU D.MENU	D. Menu / Top
MENU SRCH MODE	SRCH Mode	OPT-TOOLS SETUP	Setup / OPT /
VOLUME +	Vol +	+ VOL	Vol +
	UP Preset / CH+		Up
	Left		Left
ENTER	Enter	OK	OK
A-E	Right / A-E		Right
	Down		Down
–	Vol -	VOL –	Vol -
RETURN MEMORY	Memory	LIST SMART	Smart / List
PARAMETER DISPLAY	Parameter	HOME MENU	Menu / Home
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
REC	Rec	REC MODE	Rec / Rec Mode
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Original		Rechange	
	<<	TUNE-	<< / Tune-
EON	>>	TUNE+	>> / Tune+
MODE – PTY	I <<	PRESET-	I << / Preset-
SEEK – START	>>I	PRESET+	>>I / Preset+
CLASSICAL 1	1	TV 1	1
LIVE/CLUB 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3
MOVIE 4	4	VIDEO 4	4
STEREO 5	5	TAPE 5	5
ENHANCER 6	6	TUNER 6	6
SUR. DECODE 7	7	AUX-HDD 7	7
STRAIGHT 8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
EXTD SUR. +10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
PURE DIRECT ENT	ENT	SHIFT + OK	Shift + OK
AUDIO SEL AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Rechange	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
EON	>>	TUNE+	>> / Tune+
MODE – PTY	I <<	PRESET-	I << / Preset-
SEEK – START	>>I	PRESET+	>>I / Preset+
TITLE BAND	Title	TITLE SOUND	Sound / Title
AUDIO SEL AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
MENU SRCH MODE	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
A-E	Right		Right

Original		Rechange	
	Down		Down
RETURN MEMORY	Return	RETURN BACK	Back / Return
VOLUME +	Vol +	+ VOL	Vol +
PURE DIRECT ENT	ENT	LIST SMART	Smart / List
–	Vol -	VOL –	Vol -
PARAMETER DISPLAY	Display	MEDIA DISPLAY	Display / Media
CLASSICAL 1	1	TV 1	1
LIVE/CLUB 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3
MOVIE 4	4	VIDEO 4	4
STEREO 5	5	TAPE 5	5
ENHANCER 6	6	TUNER 6	6
SUR. DECODE 7	7	AUX-HDD 7	7
STRAIGHT 8	8	USB 8	8
9	9	BLUETOOTH 9	9
EXTD SUR. +10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0

Original		Rechange	
EXTD SUR. +10	+10 Multi	PC FAV MARKER	Fav / Marker / PC
STANDBY	Power Multi	SHIFT +	Shift + Power
	Play Multi	SHIFT + SLOW	Shift + Play /
	Pause Multi	SHIFT + STEP-FREEZE	Shift + Pause / Step /
	Stop Multi	SHIFT + HOLD	Shift + Stop /
REC	Rec Multi	SHIFT + REC MODE	Shift + Rec / Rec Mode
	<< Multi	SHIFT + TUNE-	Shift + << /
EQN	>> Multi	SHIFT + TUNE+	Shift + >> /
MODE – PTY	I << Multi	SHIFT + PRESET-	Shift + I << / Preset-
SEEK – START	>>I Multi	SHIFT + PRESET+	Shift + >>I / Preset+
TITLE BAND	Title Multi	SHIFT + TITLE SOUND	Shift + Sound / Title
AUDIO SEL AUDIO	Audio Multi	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
MENU SRCH MODE	Menu Multi	SHIFT + HOME MENU	Shift + Menu /
	Up Multi	SHIFT +	Shift + Up
	Left Multi	SHIFT +	Shift + Left
ENTER	Enter Multi	SHIFT + OK	Shift + OK
A-E	Right Multi	SHIFT +	Shift + Right

Original		Rechange	
	Down Multi	SHIFT +	Shift + Down
RETURN MEMORY	Return Multi	SHIFT + RETURN BACK	Shift + Back / Return
PURE DIRECT ENT	ENT Multi	SHIFT + LIST SMART	Shift + Smart / List
PARAMETER DISPLAY	Display Multi	SHIFT + MEDIA DISPLAY	Shift + Display / Media
CLASSICAL 1	1 Multi	SHIFT + TV 1	Shift + 1
LIVE/CLUB 2	2 Multi	SHIFT + DVD 2	Shift + 2
ENTERTAIN 3	3 Multi	SHIFT + CD-STB 3	Shift + 3
MOVIE 4	4 Multi	SHIFT + VIDEO 4	Shift + 4
STEREO 5	5 Multi	SHIFT + TAPE 5	Shift + 5
ENHANCER 6	6 Multi	SHIFT + TUNER 6	Shift + 6
SUR. DECODE 7	7 Multi	SHIFT + AUX-HDD 7	Shift + 7
STRAIGHT 8	8 Multi	SHIFT + USB 8	Shift + 8
9	9 Multi	SHIFT + BLUETOOTH 9	Shift + 9
0	0 Multi	SHIFT + HDMI-SAT 0	Shift + 0