Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	✓	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search
	Red / <<	TUNE-	<< / Tune-
	Green / Stop	APP REPEAT	Green / APP / Repeat
	Green / Stop	HOLD	Stop / Hold

Original		Rechange	
	Yellow / Play	SLOW	Play / Slow
	Yellow / Play	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / >>	TUNE+	>> / Tune+
	Blue / >>	Prime Video RANDOM	Blue / Prime Video / Random
	Up		Up
	Left		Left
ok	OK	OK	OK
	Right		Right
	Down		Down
SFI	SFI	TOP MENU D.MENU	D.Menu / Top
EXIT	Exit / Recall	RETURN BACK	Back / Return
EXIT	Exit / Recall	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
+	Prog +	CH PAGE +	CH+ / Page+
TV RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/Radio /
+	Vol +	VOL +	Vol +
PROG	Prog -	CH PAGE -	CH- / Page-

Original	Rechange	Original	Rechange
MENU Menu	HOME MENU Menu / Home		
VOL - Vol -	VOL - Vol -		
TV/SAT TV/ SAT	LIST SMART Smart / List		
TXT TXT	GOTO TEXT Text / Goto		
STOP Stop	STEP-FREEZE II Pause / Step / Freeze		
EXT EXT	MEDIA DISPLAY Display / Media		
SAT1 SAT1 + OK	SHIFT + DVD 2 Shift + 2		
SAT2 SAT2 + OK	SHIFT + CD-STB 3 Shift + 3		
TV TV + OK	SHIFT + TV 1 Shift + 1		
PIP	FORMAT PICTURE Picture / Format		

Original	Rechange	Original	Rechange
Mute	Mute / Dimmer	Green / Stop	Stop / Hold
Power	Power	Yellow / Play	Play / Slow
1	1	Yellow / Play	Yellow / YouTube / Repeat
2	2	Blue / >>	>> / Tune+
3	3	Blue / >>	Blue / Prime Video / Random
4	4	Up	Up
5	5	Left	Left
6	6	OK	OK
7	7	Right	Right
8	8	Down	Down
9	9	SFI	D.Menu / Top
✓	Guide / EPG / -/--	Exit / Recall	Exit / Cancel / Clear
0	0	Exit / Recall	Back / Return
A/B	Shift + Yellow / YouTube /	Info	Info / Angle
Red / <<	<< / Tune-	Prog +	CH+ / Page+
Red / <<	Red / Netflix / Search	TV / Radio	TV/Radio /
Green / Stop	Green / APP / Repeat	Vol +	Vol +

Original	Rechange	Original	Rechange
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol -	Vol -		
TV/SAT	Smart / List		
TXT	Text / Goto		
Stop	Pause / Step / Freeze		
EXT	Display / Media		
SAT1 + OK	SHIFT + 2		
SAT2 + OK	SHIFT + 3		
TV + OK	SHIFT + 1		

Original	Rechange	Original	Rechange
Mute	Mute / Dimmer	Green / Stop	Green / APP / Repeat
Power	Power	Yellow / Play	Play / Slow
1	1	Yellow / Play	Yellow / YouTube / Repeat
2	2	Blue / >>	>> / Tune+
3	3	Blue / >>	Blue / Prime Video / Random
4	4	Up	Up
5	5	Left	Left
6	6	OK	OK
7	7	Right	Right
8	8	Down	Down
9	9	SFI	D.Menu / Top
✓	Guide / EPG / -/--	Exit / Recall	Back / Return
0	0	Exit / Recall	Exit / Cancel / Clear
A/B	Shift + Yellow / YouTube /	Info	Info / Angle
Red / <<	Red / Netflix / Search	Prog +	CH+ / Page+
Red / <<	<< / Tune-	TV / Radio	TV/Radio /
Green / Stop	Stop / Hold	Vol +	Vol +

Original	Rechange	Original	Rechange
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol -	Vol -		
TV/SAT	Smart / List		
TXT	Text / Goto		
Stop	Pause / Step / Freeze		
EXT	Display / Media		
SAT1 + OK	SHIFT + DVD 2	Shift + 2	
SAT2 + OK	SHIFT + CD-STB 3	Shift + 3	
TV + OK	SHIFT + TV 1	Shift + 1	