Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
TUNER/BAND	Tuner / Band	SEARCH TV/R	TV/R
FM MODE	FM Mode	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
≥10	>10	-/-- GUIDE	Guide
CD	CD	C	Yellow
⏮	I << CD	<<	I <<

Original		Rechange	
⏭	>>I CD	>>I	>>I
PROGRAM	Program	SHIFT + PROG SLEEP	Shift + Sleep
▶	Play CD	PLAY MODE ▶	Play
⏸	Pause CD	⏸	Pause
■	Stop CD	■	Stop
CANCEL	Cancel	RETURN BACK	Back
DECK1/2	Deck 1/2	B	Green
◀◀	<< Deck	<<	<<
▶▶	>> Deck	>>	>>
REC PAUSE	Rec Pause Deck	REC MODE	Rec
◀	< Deck	◀	Left
■	Stop Deck	OK	Ok
▶	> Deck	▶	Right
ON/FLAT	On Flat	HOME SMART	Smart
EQ SPACE MODE	EQ Space Mode	APP MEDIA	Media
NCE R	Balance R	+ CH	Ch +
L BA	Balance L	CH −	Ch -

Original	Rechange	Original	Rechange
Volume+	Vol +		
Volume-	Vol -		
Muting	Mute		