# Mandis shop

Panasonic N2QAYB001050

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Display | Info |
| Dimmer | Smart | Sound | Dual |
| Open/Close CD | Eject | Play Menu | Menu |
| Bluetooth | Media | Album Up | Up |
| CD/USB | AV | OK | Ok |
| Radio/EXT-In | TV/R | Album Down | Down |
| << | << | | |
| Pause | Pause | | |
| >>I | >>I | | |
| Stop | Stop | | |
| I << | I << | | |
| Vol + | Vol + | | |
| >> | >> | | |
| Vol - | Vol - | | |
| Play | Play | | |
| Mute | Mute | | |
| Setup | Options | | |

https://mandis-rentes.com/fr/Panasonic/10643-6590-telecommande-de-replacement-pour-Panasonic-N2QAYB001050.html