Original	Rechange	Original	Rechange
Power	Power	Display	Display / Media
Open/Close	Eject / Surround	Title	Sound / Title
Setup	Setup / OPT /	Menu	Menu / Home
Angle	Info / Angle	Up	Up
Random	Shift + Prime Video / RANDOM — Shift + Blue / Prime	Down	Down
1	1	Right	Right
2	2	Left	Left
3	3	OK	OK
4	4	Search	Shift + Netflix / SEARCH — Shift + Red / Netflix /
5	5	Repeat	Shift + APP / REPEAT — Shift + Green / APP /
6	6	A-B	Shift + YouTube / REPEAT A-B — Shift + Yellow / YouTube /
7	7	Zoom	Zoom / Size
8	8	Pause	Pause / Step / Freeze
9	9	Stop	Stop / Hold
0	0	Play	Play / Slow
+10	Guide / EPG / -/--	Vol +	Vol +
Language	Audio / Lang I/II	Vol -	Vol -

Original	Rechange	Original	Rechange
I <<	I << / Preset-		
>>I	>>I / Preset+		
<<	<< / Tune-		
>>	>> / Tune+		
Resume	D. Menu / Top		
Subtitle	Subtitle / EQ		
Slow	Shift + Play /		
Program	TV/ Radio /		
Vocal-Assist	Rec / Rec Mode		
PBC	Text / Goto		
Mute	Mute / Dimmer		
P/I	Picture / Format		
Red/ Edit	Red / Netflix / Search		
Blue/ Target	Blue / Prime Video / Random		
Green/ Copy	Green / APP / Repeat		
Yellow/ Delete	Yellow / YouTube / Repeat		