Original		Rechange	
	Power		Power
ENERGY SAVING	e/ Energy Savi ng	SHIFT + OK	Shi f t + OK
AV MODE	AV Mode	GOTO TEXT	Text / Goto
INPUT	I nput	RDS AV INPUT	AV / I nput / RDS
TV	TV	PROGRAM TV/RADIO	TV/ Radi o /
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD - STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX - HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
LIST	List	LIST SMART	Smart / List
Q.VIEW	Q. Vi ew	OPT-TOOLS SETUP	Setup / OPT / Tool s

Original		Rechange	
MARK FAV	FAV/ Mark	PC FAV MARKER	Fav / Marker / PC
CHAR/NUM RATIO	Rati o	FORMAT PICTURE	Pi cture / Format
DELETE MUTE	Mute/ Del ete	DIMMER MUTE	Mute / Di mmer
+ VOL	Vol +	+ VOL	Vol +
- VOL	Vol -	- VOL	Vol -
CH	CH+	CH PAGE	CH+ / Page+
CH	CH-	CH PAGE	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
NetCast	Net cast	MEDIA DISPLAY	Di spl ay / Medi a
Q.MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
	Up		Up
	Down		Down
	Left		Left
	Ri ght		Ri ght
ENTER	Ent er	OK	OK
BACK	Back	RETURN BACK	Back / Return
SIMPLINK	Si mpl i nk	SIZE ZOOM	Zoom / Si ze

Original		Rechange		Original		Rechange	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
■	Stop	HOLD ■	Stop / Hold				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				