Original		Rechange	
POWER	Power		Power
GUIDE	Guide	GUIDE EPG	Guide / EPG / -/--
TV	Input Tv	PROGRAM TV/RADIO	TV/Radio /
AV	Input AV	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home
TEXT	Text	GOTO TEXT	Text / Goto
STTL/AD	STTL/AD	EQ SUBTITLE	Subtitle / EQ
ASPECT	Aspect	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
APPS	APPS	SHIFT + APP REPEAT	Shift + Green / APP /
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
RETURN	Return	RETURN BACK	Back / Return
▲	Up	▲	Up
▼	Down	▼	Down

Original		Rechange	
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	OK
R	Red	NETFLIX SEARCH	Red / Netflix / Search
G	Green	APP REPEAT	Green / APP / Repeat
Y	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
B	Blue	Prime Video RANDOM	Blue / Prime Video / Random
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH ∧	CH+	CH PAGE +	CH+ / Page+
CH ∨	CH-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2abc	2	DVD 2	2
3def	3	CD-STB 3	3
4ghi	4	VIDEO 4	4
5jkl	5	TAPE 5	5

Original		Rechange		Original	Rechange
6mno	6	TUNER 6	6		
7pqrs	7	AUX - HDD 7	7		
8tuv	8	USB 8	8		
9wxyz	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
LAST VIEW	Last View	PC FAV MARKER	Fav / Marker / PC		
HEXA BOOST	Hexa Boost	TITLE SOUND	Sound / Title		
⏮ / ◀◀	⏮/ <<	TUNE- ◀◀	<< / Tune-		
▶	Play	SLOW ▶	Play / Slow		
⏭ / ▶▶	>>/ >>I	TUNE+ ▶▶	>> / Tune+		
■	Stop	HOLD ■	Stop / Hold		
❚❚	Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze		
●	Rec	REC MODE ●	Rec / Rec Mode		
OFF TIMER	Off Timer	TIMER SLEEP	Sleep / Timer		
MY APP	My APP	LIST SMART	Smart / List		
eHELP ?	e-Help	LANG I/II AUDIO	Audio / Lang I/II		