Original		Rechange	
	Power		Power
	1	TV 1	1
ABC	2	DVD 2	2
DEF	3	CD - STB 3	3
Audio PIP	PI P	ANGLE INFO	I nf o / Angl e
GHI	4	VIDEO 4	4
JKL	5	TAPE 5	5
MNO	6	TUNER 6	6
	[<>]	FORMAT PICTURE	Pi cture / Format
	>I	PRESET+	>>I / Preset +
PQRS	7	AUX - HDD 7	7
TUV	8	USB 8	8
WXYZ	9	BLUETOOTH 9	9
	?	LIST SMART	Smart / Li st
	I <	PRESET-	I << / Preset -
	0	HDMI - SAT 0	0
	Mut e	DIMMER MUTE	Mut e / Di mmer

Original		Rechange	
OSD	i / OSD	MEDIA DISPLAY	Di spl ay / Medi a
Disc Menu	Z/ Di sc Menu	HOME MENU	Menu / Home
P+	Up		Up
P+	P+	CH PAGE +	CH+ / Page+
	Left		Left
	Vol -	VOL −	Vol -
OK	OK	OK	OK
	Ri ght		Ri ght
	Vol +	VOL +	Vol +
TXT	TXT	GOTO TEXT	Text / Goto
TXT	<<	TUNE-	<< / Tune-
P-	Down		Down
P-	P-	CH PAGE −	CH- / Page-
TV-G	TV- G	-/-- GUIDE EPG	Gui de / EPG / -/--
TV-G	>>	TUNE+	>> / Tune+
	Red/ I mage/ I >	NETFLIX SEARCH	Red / Netf l i x / Search
	Green/ Ti mer	APP REPEAT	Green / APP / Repeat

Original	Rechange	Original	Rechange
Play	SLOW Play / Slow		
Yellow/Pause	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Pause	STEP-FREEZE Pause / Step / Freeze		
Blue/Sound	Prime Video RANDOM Blue / Prime Video / Random		
Stop	HOLD Stop / Hold		
Blue/Sound	TITLE SOUND Sound / Title		

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	i / OSD		Display / Media

Original		Rechange	
	Disc Menu		D. Menu / Top
	Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/Picture		Picture / Format
	Red/Picture		Red / Netflix / Search

Original	Rechange	Original	Rechange
Green / Timer	TIMER SLEEP — Sleep / Timer		
Play	SLOW — Play / Slow		
Green / Timer	APP REPEAT — Green / APP / Repeat		
Yellow/Pause	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
Pause	STEP-FREEZE — Pause / Step / Freeze		
Blue/Sound	TITLE SOUND — Sound / Title		
Stop	HOLD — Stop / Hold		
Blue/Sound	Prime Video RANDOM — Blue / Prime Video / Random		

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	Mute		Mute / Dimmer

Original		Rechange	
	i / OSD		Display / Media
	Z/ Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/ Image/ I>		Red / Netflix / Search
	Red/ Image/ I>		Shift + Play / Slow

Original	Rechange	Original	Rechange
Green/Timer	APP REPEAT Green / APP / Repeat		
Play	SLOW Play / Slow		
Green/Timer	TIMER SLEEP Sleep / Timer		
Pause	STEP-FREEZE Pause / Step / Freeze		
Yellow/Pause	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue/Sound	Prime Video RANDOM Blue / Prime Video / Random		
Stop	HOLD Stop / Hold		
Blue/Sound	TITLE SOUND Sound / Title		

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	PIP/Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	i/OSD		Display / Media

Original		Rechange	
	Z/Disc Menu		Menu / Home
	P+		CH+ / Page+
	Up		Up
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	P-		CH- / Page-
	Down		Down
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/Image/I>		Picture / Format
	Red/Image/I>		Red / Netflix / Search
	Green/Timer		Green / APP / Repeat

Original	Rechange	Original	Rechange
Play	SLOW Play / Slow		
Green/Timer	TIMER SLEEP Sleep / Timer		
Yellow/Pause	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Pause	STEP-FREEZE Pause / Step / Freeze		
Blue/Sound	Prime Video RANDOM Blue / Prime Video / Random		
Stop	HOLD Stop / Hold		
Blue/Sound	TITLE SOUND Sound / Title		