Original		Rechange	
POWER	Power		Power
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
P.MODE	P.Mode --	PC FAV MARKER	Fav / Marker / PC
TEXT	Text	GOTO TEXT	Text / Goto
HOLD	Hold	SHIFT + HOLD	Shift + Stop /
S.MODE	S.Mode --	-/-- GUIDE EPG	Guide / EPG / -/--
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SIZE	Size	SIZE ZOOM	Zoom / Size
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
SUBPAGE	Subpage	SURROUND	Eject / Surround
MEDIA	Media	LIST SMART	Smart / List
	Play / Pause	SLOW	Play / Slow
	Play / Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Rechange	
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Rec	REC MODE	Rec / Rec Mode
	Stop	HOLD	Stop / Hold
	I<<	PRESET-	I<< / Preset-
INDEX	>>I / Index	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Left		Left
OK	OK	OK	OK
	Right		Right
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer

Original	Rechange	Original	Rechange
CH+ / Page+	CH+ / Page+	Smart TV	Picture / Format
Vol -	Vol -	Mouse	Sound / Title
Display	Display / Media		
CH- / Page-	CH- / Page-		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
-/--	-/--		
0	0		
Recall	Back / Return		
Source	AV / Input / RDS		

Original		Rechange	
POWER	Power		Power
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
TEXT	Text	GOTO TEXT	Text / Goto
HOLD	Hold	SHIFT + HOLD	Shift + Stop /
S.MODE	S. Mode	TITLE SOUND	Sound / Title
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SIZE	Size	SIZE ZOOM	Zoom / Size
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
SUBPAGE	Subpage	SURROUND	Eject / Surround
MEDIA	Media	LIST SMART	Smart / List
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Rechange	
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Rec	REC MODE	Rec / Rec Mode
	Stop	HOLD	Stop / Hold
	I<<	PRESET-	I<< / Preset-
INDEX	>>I / Index	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Left		Left
OK	OK	OK	OK
	Right		Right
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer

Original	Rechange	Original	Rechange
CH+	CH+ / Page+	FAV	Fav / Marker / PC
Vol -	Vol -	TVG	Guide / EPG / -/--
Display	Display / Media		
CH-	CH- / Page-		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
-/--	-/--		
0	0		
Recall	Back / Return		
Source	AV / Input / RDS		