| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| FUNCTION TV SOURCE | Function Tv | RDS AV INPUT | AV / Input / RDS |
| | Eject | SURROUND | Eject / Surround |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| V-SOUND | V- Sound | LANG I/II AUDIO | Audio / Lang I/II |
| V-SOUND | V- Sound | SHIFT + TITLE SOUND | Shift + Sound / Title |
| 0 | 0 | HDMI - SAT 0 | 0 |
| DSP/EQ | DSP/ EQ | EQ SUBTITLE | Subtitle / EQ |

| Original | | Rechange | |
|---|---|---|---|
| | I << | PRESET- | I << / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | Stop | HOLD | Stop / Hold |
| | Play | SLOW | Play / Slow |
| | Pause | STEP - FREEZE | Pause / Step / Freeze |
| VOL | Vol + | VOL | Vol + |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| TUNING / CH | Tuning/ CH+ | SHIFT + TUNE+ | Shift + >> / |
| TUNING / CH | Tuning/ CH+ | CH PAGE | CH+ / Page+ |
| VOL | Vol - | VOL | Vol - |
| REPEAT | Repeat | SHIFT + APP REPEAT | Shift + Green / APP / |
| TUNING / CH | Tuning/ CH- | CH PAGE | CH- / Page- |
| TUNING / CH | Tuning/ CH- | SHIFT + TUNE- | Shift + << / |
| DISC MENU | Disc Menu | TOP MENU D.MENU | D. Menu / Top |
| MENU | Menu | HOME MENU | Menu / Home |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| TITLE MENU Title Menu | TITLE SOUND Sound / Title | | |
| TOOLS Tools | OPT-TOOLS SETUP Setup / OPT / | | |
| Up | Up | | |
| INFO Info | ANGLE INFO Info / Angle | | |
| Left | Left | | |
| Enter | OK OK | | |
| Right | Right | | |
| RETURN Return | RETURN BACK Back / Return | | |
| Down | Down | | |
| EXIT Exit | CLEAR EXIT CANCEL Exit / Cancel / Clear | | |
| A Red | NETFLIX SEARCH Red / Netflix / Search | | |
| TUNER MEMORY B Green/Tuner | APP REPEAT Green / APP / Repeat | | |
| MO/ST C Yellow/MO/ST | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| CD RIPPING D Blue/CD Ripping | Prime Video RANDOM Blue / Prime Video / Random | | |
| DIMMER Dimmer | SHIFT + DIMMER MUTE Shift + Mute / Dimmer | | |
| S.VOL S. Vol | LIST SMART Smart / List | | |
| AUDIO UPSCALE P.BASS P. Bass/Audio Upscale | MEDIA DISPLAY Display / Media | | |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Pause | Pause / Step / Freeze |
| Function Tv | AV / Input / RDS | Vol + | Vol + |
| Sleep | Sleep / Timer | Mute | Mute / Dimmer |
| 1 | 1 | CH+ | CH+ / Page+ |
| 2 | 2 | Vol - | Vol - |
| 3 | 3 | CH- | CH- / Page- |
| 4 | 4 | Menu | Menu / Home |
| 5 | 5 | Tools | Setup / OPT / |
| 6 | 6 | Up | Up |
| 7 | 7 | Info | Info / Angle |
| 8 | 8 | Left | Left |
| 9 | 9 | Enter | OK |
| 0 | 0 | Right | Right |
| << | << / Tune- | Return | Back / Return |
| >> | >> / Tune+ | Down | Down |
| Stop | Stop / Hold | Exit | Exit / Cancel / Clear |
| Play | Play / Slow | Red | Red / Netflix / Search |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| TUNER MEMORY B Green | APP REPEAT Green / APP / Repeat | | |
| MO/ST C Yellow | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| CD RIPPING D Blue | Prime Video RANDOM Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |