Mandis shop

# Panasonic N2QAYB000450

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| LENS | Lens | GUIDE EPG | Guide / EPG / -/-- |
| PICTURE MODE | Picture Mode | FORMAT PICTURE | Picture / Format |
| PICTURE ADJUSTMENT | Picture | SHIFT + FORMAT PICTURE | Shift + Picture / Format |
| PICTURE ADJUSTMENT | Picture | SIZE ZOOM | Zoom / Size |
| MEMORY LOAD | Memory Load | PC FAV MARKER | Fav / Marker / PC |
| VIERA Link | Viera Link | LIST SMART | Smart / List |
| WAVEFORM MONITOR | Waveform | MEDIA DISPLAY | Display / Media |
| FREEZE | Freeze | STEP-FREEZE | Pause / Step / Freeze |
| MENU | Menu | HOME MENU | Menu / Home |
| DEFAULT | Default | ANGLE INFO | Info / Angle |
| | Up | | Up |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| | Down | | Down |
| OPTION SUB MENU | Sub Menu/Option | OPT-TOOLS SETUP | Setup / OPT / Tools |

| Original | | Rechange | |
|---|---|---|---|
| BACK/ RETURN | Back/Return | RETURN BACK | Back / Return |
| INPUT SELECT | Input Select | RDS AV INPUT | AV / Input / RDS |
| FUNCTION | Function | TOP MENU D.MENU | D.Menu / Top |

https://mandis.tv/fr/Panasonic/1665-8419-telecommande-remplacement-pour-Panasonic-N2QAYB000450.htm