| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Vol - | Vol - |
| 1 | 1 | Left | Left |
| 2 | 2 | OK | OK |
| 3 | 3 | P- | CH- / Page- |
| 4 | 4 | Down | Down |
| 5 | 5 | AUX | Shift + 7 |
| 6 | 6 | TXT | Text / Goto |
| 7 | 7 | Red/Picture | Red / Netflix / Search |
| 8 | 8 | Green/Timer | Green / APP / Repeat |
| 9 | 9 | Yellow/Format | Yellow / YouTube / Repeat |
| i | Info / Angle | Blue/Audio | Blue / Prime Video / Random |
| 0/AV | 0 | Colour- | << / Tune- |
| Mute | Mute / Dimmer | Colour+ | >> / Tune+ |
| Up | Up | Brightness- | I<< / Preset- |
| P+ | CH+ / Page+ | Brightness+ | >>I / Preset+ |
| Vol + | Vol + | | |
| Right | Right | | |

| Original | Rechange |
|---|---|
| Power | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| i | Info / Angle |
| 0/AV | 0 |
| Mute | Mute / Dimmer |
| Up | Up |
| P+ | CH+ / Page+ |
| Right | Right |
| Vol + | Vol + |

| Original | Rechange |
|---|---|
| Vol - | Vol - |
| Left | Left |
| OK | OK |
| P- | CH- / Page- |
| Down | Down |
| AUX | Shift + 7 |
| TXT | Text / Goto |
| Red/Picture | Red / Netflix / Search |
| Green/Timer | Green / APP / Repeat |
| Yellow/Format | Yellow / YouTube / Repeat |
| Blue/Audio | Blue / Prime Video / Random |
| Colour- | << / Tune- |
| Colour+ | >> / Tune+ |
| Brightness- | I<< / Preset- |
| Brightness+ | >>I / Preset+ |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | | |
| Rec | Rec / Rec Mode | | |
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| P+ | CH+ / Page+ | | |
| >> | >> / Tune+ | | |
| << | << / Tune- | | |
| Play | Play / Slow | | |
| P- | CH- / Page- | | |
| AUX | 7 | | |
| TXT | Text / Goto | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |