Original		Rechange	
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SYSTEM	System	HOME MENU	Menu / Home
GO TO	Go To	GOTO TEXT	Text / Goto
L/R	L/R	TOP MENU D.MENU	D.Menu / Top
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
REP A-B	Rep A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Rechange	
6	6	TUNER 6	6
ANGLE	Angle	ANGLE INFO	Info / Angle
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
DIGEST	Digest	TIMER SLEEP	Sleep / Timer
0	0	HDMI-SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SKIP	I<< SKip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
SCAN	<< Scan	TUNE-	<< / Tune-
SCAN	Scan >>	TUNE+	>> / Tune+
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
TITLE	Title	TITLE SOUND	Sound / Title

Original		Rechange		Original	Rechange
PBC	PBC	FORMAT PICTURE	Picture / Format		
	Up		Up		
	Left		Left		
SELECT	Select	OK	OK		
	Right		Right		
OSD	OSD	MEDIA DISPLAY	Display / Media		
	Down		Down		
RETURN	Return	RETURN BACK	Back / Return		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
SLOW	Slow	SHIFT + SLOW	Shift + Play /		
STEP	Step	SHIFT + STEP - FREEZE	Shift + Pause / Step /		
RESUME	Resume	REC MODE	Rec / Rec Mode		
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /		
FUNCTION	Function	LIST SMART	Smart / List		
-	-	VOL -	Vol -		
+	+	+ VOL	Vol +		