Original		Rechange		Original		Rechange	
ON AVR Power	AVR Power On	Power		DEF 3	3	CD-STB 3	3
OFF Power	AVR Power Off	SHIFT + Power	Shift + Power	GHI 4	4	VIDEO 4	4
Cable/Sat	Cable/Sat	SHIFT + HDMI-SAT 0	Shift + 0	JKL 5	5	TAPE 5	5
Disc	Disc	SHIFT + DVD 2	Shift + 2	MNO 6	6	TUNER 6	6
DVR	DVR	SHIFT + CD-STB 3	Shift + 3	PQRS 7	7	AUX-HDD 7	7
Radio	Radio	SHIFT + TUNER 6	Shift + 6	TUV 8	8	USB 8	8
TV	TV	SHIFT + TV 1	Shift + 1	WXYZ 9	9	BLUETOOTH 9	9
USB	USB	SHIFT + USB 8	Shift + 8	LAST	Last	RETURN BACK	Back / Return
Game	Game	SHIFT + VIDEO 4	Shift + 4	>9 0	0	HDMI-SAT 0	0
Media Server	Media Server	SHIFT + BLUETOOTH 9	Shift + 9	BACK/ EXIT	Back/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Network	Network	SHIFT + TAPE 5	Shift + 5	▲	Up	▲	Up
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7	MENU	Menu	HOME MENU	Menu / Home
Audio Effects	Audio Effects	LANG I/II AUDIO	Audio / Lang I/II	◀	Left	◀	Left
Video Modes	Video Modes	FORMAT PICTURE	Picture / Format	OK	OK	OK	OK
Surround Modes	Surround Modes	SURROUND ⏏	Eject / Surround	▶	Right	▶	Right
1	1	TV 1	1	▼	Down	▼	Down
ABC 2	2	DVD 2	2	A	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Rechange	Original	Rechange
Green	Green / APP / Repeat	Sleep	Sleep / Timer
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Vol +	Vol +		
Mute	Mute / Dimmer		
CH/Page Up	CH+ / Page+		
Vol -	Vol -		
CH/Page Down	CH- / Page-		
I<<	I<< / Preset-		
Pause	Pause / Step / Freeze		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Stop	Stop / Hold		
AVR	Smart / List		
Info	Info / Angle		

Original		Rechange	
ON Device	Disc Power On		Power
OFF Power	Disc Power Off	SHIFT +	Shift + Power
Disc	Disc	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
LAST	Last	RETURN BACK	Back / Return
>9 0	0	HDMI - SAT 0	0
BACK/ EXIT	Back/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
MENU	Menu	HOME MENU	Menu / Home

Original		Rechange	
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
A	Red	NETFLIX SEARCH	Red / Netflix / Search
B	Green	APP REPEAT	Green / APP / Repeat
C	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
D	Blue	Prime Video RANDOM	Blue / Prime Video / Random
VOL +	Vol +	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOL −	Vol -	VOL −	Vol -
	I<<	PRESET-	I<< / Preset-
	Pause	STEP - FREEZE	Pause / Step / Freeze
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow

https://mandis.tv/fr/harman-kardon-AVR370-AVR370-AVR370

Original	Rechange	Original	Rechange
>>	TUNE+ >> / Tune+		
Rec	REC MODE Rec / Rec Mode		
Stop	HOLD Stop / Hold		

Original		Rechange	
ON Device	DVR Power On		Power
DVR	DVR	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
>9 0	0	HDMI - SAT 0	0
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
	Right		Right
	Down		Down

Original		Rechange	
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH Page ▲	CH/ Page Up	+ CH PAGE	CH+ / Page+
VOL –	Vol -	VOL –	Vol -
CH Page ▼	CH/ Page Down	CH PAGE –	CH- / Page-

Original		Rechange	
ON AVR Power	AVR Power On	Power	
OFF Power	AVR Power Off	SHIFT + Power	Shift + Power
Cable/Sat	Cable/SAT	SHIFT + HDMI - SAT 0	Shift + 0
Disc	Disc	SHIFT + DVD 2	Shift + 2
DVR	DVR	SHIFT + CD - STB 3	Shift + 3
Radio	Radio	SHIFT + TUNER 6	Shift + 6
TV	TV	SHIFT + TV 1	Shift + 1
USB	USB	SHIFT + USB 8	Shift + 8
Game	Game	SHIFT + VIDEO 4	Shift + 4
Media Server	Media Server	SHIFT + BLUETOOTH 9	Shift + 9
Network	Network	SHIFT + TAPE 5	Shift + 5
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
Audio Effects	Audio Effects	LANG I/II AUDIO	Audio / Lang I/II
Video Modes	Video Modes	FORMAT PICTURE	Picture / Format
Surround Modes	Surround Modes	SURROUND	Eject / Surround
1	1	TV 1	1
ABC 2	2	DVD 2	2

Original		Rechange	
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
LAST	Last	RETURN BACK	Back / Return
>9 0	0	HDMI - SAT 0	0
BACK/ EXIT	Back/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Up	▲	Up
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
A	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Rechange	Original	Rechange
Green	Green / APP / Repeat	Info	Info / Angle
Yellow	Yellow / YouTube / Repeat	Sleep	Sleep / Timer
Blue	Blue / Prime Video / Random		
Vol +	Vol +		
Mute	Mute / Dimmer		
CH/ Page Up	CH+ / Page+		
Vol -	Vol -		
CH/ Page Down	CH- / Page-		
I<<	I<< / Preset-		
Pause	Pause / Step / Freeze		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
AVR	Smart / List		