| Original | | Rechange | |
|---|---|---|---|
| | POWER | | Power |
| | ←○ | SHIFT + LIST SMART | Shift + Smart / List |
| | ☼*/Ö | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| | ☼²/♀ | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| | SOURCE | RDS AV INPUT | AV / Input / RDS |
| | PRESETS | LIST SMART | Smart / List |
| | ┼┼┼ | OPT-TOOLS SETUP | Setup / OPT / |
| | ♫/☺◘ | MEDIA DISPLAY | Display / Media |
| | SLEEP | TIMER SLEEP | Sleep / Timer |
| 1 | 1 . /@ | TV 1 | 1 |
| 2 abc | 2 abc | DVD 2 | 2 |
| 3 def | 3 def | CD - STB 3 | 3 |
| 4 ghi | 4 ghi | VIDEO 4 | 4 |
| 5 jkl | 5 jkl | TAPE 5 | 5 |
| 6 mno | 6 mno | TUNER 6 | 6 |
| 7 pqrs | 7 pqrs | AUX - HDD 7 | 7 |
| 8 tuv | 8 tuv | USB 8 | 8 |

| Original | | Rechange | |
|---|---|---|---|
| 9 wxyz | 9 wxyz | BLUETOOTH 9 | 9 |
| | TV | PROGRAM TV/ RADIO | TV/ Radio / |
| 0 | 0 | HDMI - SAT 0 | 0 |
| | ↔ | SHIFT + RETURN BACK | Shift + Back / Return |
| | TV GUIDE | -/-- GUIDE EPG | Guide / EPG / -/-- |
| | [≡] | GOTO TEXT | Text / Goto |
| | MENU | HOME MENU | Menu / Home |
| | Q. MENU | TOP MENU D.MENU | D. Menu / Top |
| | UP | | Up |
| | LEFT | | Left |
| OK | OK | OK | OK |
| | RIGHT | | Right |
| | DOWN | | Down |
| | BACK | RETURN BACK | Back / Return |
| | ⊸ | FORMAT PICTURE | Picture / Format |
| | EXIT | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | ☼FAV | PC FAV MARKER | Fav / Marker / PC |

| Original | | Rechange | |
|---|---|---|---|
| | VOL+ | | Vol + |
| | MUTE | | Mute / Dimmer |
| | P+ | | CH+ / Page+ |
| | VOL- | | Vol - |
| | INFO | | Info / Angle |
| | P- | | CH- / Page- |
| | REC | | Rec / Rec Mode |
| | PLAY | | Play / Slow |
| | PAUSE | | Pause / Step / Freeze |
| | STOP | | Stop / Hold |
| | LANG. | | Audio / Lang I/II |
| | << | | << / Tune- |
| | >> | | >> / Tune+ |
| | [ ≡ ]... | | Sound / Title |
| | RED | | Red / Netflix / Search |
| | GREEN | | Green / APP / Repeat |
| | YELLOW | | Yellow / YouTube / Repeat |

| Original | | Rechange | |
|---|---|---|---|
| | BLUE | | Blue / Prime Video / Random |