Mandis shop

RC- 1000C

Original	Rechange	Original	Rechange
Line 1	Power		
Line2	Mute / Dimmer		
Balanced	Play / Slow		
Tape1	Pause / Step / Freeze		
Tape 2	Stop / Hold		
Phono	Rec / Rec Mode		
Source Direct On/Off	<< / Tune-		

https://mandis.tv/fr/kenwood/10624-362-telecommande-de-remplacement-pour-kenwood-rc-1000c.html